




Kodak Service & Support

 [Kodak Home Page
on Internet](#)

 [Intranet](#)

 [Table of Contents](#)

ILLUSTRATED PARTS LIST for the *Kodak Ektapro* SLIDE PROJECTOR Model 3020, 4020, 5020, 7020, and 9020 with ACCESSORIES



A028_0009AC

PLEASE NOTE The information contained herein is based on the experience and knowledge relating to the subject matter gained by Eastman Kodak Company prior to publication.

No patent license is granted by this information.


Eastman Kodak Company reserves the right to change this information without notice, and makes no warranty, express or implied, with respect to this information. Kodak shall not be liable for any loss or damage, including consequential or special damages, resulting from any use of this information, even if loss or damage is caused by Kodak's negligence or other fault.

 This equipment includes parts and assemblies sensitive to damage from electrostatic discharge. Use caution to prevent damage during all service procedures.

Table of Contents


Description	Page
Illustrated Parts List	3
Alphabetical Index	41
Numerical Index	47

Section 1: Illustrated Parts List




A028_0030DC

Item	Part No.	Description	Qty.	Notes
1	6200701	KNOB	1	Models: 3020, 4020, 5020, 7020, and 9020
2	6202254	HOUSING, UPPER	1	Models: 3020, 4020, 5020, 7020, and 9020
3	4901411	LABEL, MODEL	1	Models: 3020, 4020, 5020, 7020, and 9020
4	6203031	LABEL, MODEL	1	Model 3020
	6204022	LABEL, MODEL	1	Model 4020
	6205022	LABEL, MODEL	1	Model 5020
	6207022	LABEL, MODEL	1	Model 7020
	6209022	LABEL, MODEL	1	Model 9020
5	6202031	WINDOW	1	Models: 3020, 4020, 5020, 7020, and 9020
6	4302421	SCREW	2	Models: 3020, 4020, 5020, 7020, and 9020




A028_0029DC

Item	Part No.	Description	Qty.	Notes
1	6202071	PLATE, COVER	1	Models: 3020, 4020, and 7020
	6205102	PLATE, COVER	1	Model 5020
	6208102	PLATE, COVER	1	Model 9020
2	6202181	BUTTON	1	Models: 3020, 4020, 5020, 7020, and 9020
	6202191	BUTTON, TRAY SWITCH	1	Models: 3020, 4020, 5020, 7020, and 9020
3	6202171	BUTTON, STAND-BY	1	Models: 3020, 4020, 5020, 7020, and 9020
4	6202141	BUTTON, FORWARD FOCUS	1	Models: 3020, 4020, 5020, 7020, and 9020
5	6202131	BUTTON, REVERSE FOCUS	1	Models: 3020, 4020, 5020, 7020, and 9020
6	6202161	BUTTON, FORWARD	1	Models: 3020, 4020, 5020, 7020, and 9020
7	6202151	BUTTON, REVERSE	1	Models: 3020, 4020, 5020, 7020, and 9020
8	6202062	PLATE, COVER	1	Models: 3020, 4020, 5020, 7020, and 9020
8	6207722	PLATE, COVER-Korea	1	Model 7020




A028_0028DC

Item	Part No.	Description	Qty.	Notes
1	6200824	RING, DRIVE	1	Models: 3020, 4020, 5020, 7020, and 9020
2	6200804	HOUSING, CENTER-with CLIP	1	Models: 3020, 4020, 5020, 7020, and 9020
3	4719391	ROLLER, SHAFT	3	Models: 3020, 4020, 5020, 7020, and 9020
4	6200871	ROLLER, BEARING	3	Models: 3020, 4020, 5020, 7020, and 9020
5	6200922	LATCH	1	Models: 3020, 4020, 5020, 7020, and 9020
6	4302411	SCREW	1	Models: 3020, 4020, 5020, 7020, and 9020
7	6200911	RETAINER	8	Models: 3020, 4020, 5020, 7020, and 9020
8	6200931	ROLLER	8	Models: 3020, 4020, 5020, 7020, and 9020
9	4302421	SCREW	2	Models: 3020, 4020, 5020, 7020, and 9020
10	6217364	MOTOR	1	Models: 3020, 4020, 5020, 7020, and 9020
11	6200811	INDICATOR, FOCUS	1	Models: 3020, 4020, 5020, 7020, and 9020
12	6201881	DISK, CODER Serial No. 118 500 and above	1	Models: 3020, 4020, 5020, 7020, and 9020
13	6200861	WHEEL, GEAR	1	Models: 3020, 4020, 5020, 7020, and 9020
14	6210824	PCB, TRAY, MOTION	1	Models: 3020, 4020, 5020, 7020, and 9020
15	6200971	WHEEL, GEAR	1	Models: 3020, 4020, 5020, 7020, and 9020
16	6201521	LEVER, ZERO-new style	1	Models: 3020, 4020, 5020, 7020, and 9020
17	6200631	SPRING, new style	1	Models: 3020, 4020, 5020, 7020, and 9020
18	4301911	SCREW	2	Models: 3020, 4020, 5020, 7020, and 9020
19	4302361	SCREW	2	Models: 3020, 4020, 5020, 7020, and 9020
20	6201871	CLIP	1	Models: 3020, 4020, 5020, 7020, and 9020
21	6201861	ECCENTRIC	2	Models: 3020, 4020, 5020, 7020, and 9020
22	6205451	WARNING LABEL	1	Models: 7020 and 9020



A028_0027DC

Item	Part No.	Description	Qty.	Notes
1	6200751	RETAINER, AF	1	Models: 3020, 4020, 5020, 7020, and 9020
2	4301881	SCREW	2	Models: 3020, 4020, and 7020
	4301881	SCREW	3	Models: 5020 and 9020
3	4302541	SCREW	1	Models: 3020, 4020, 5020, 7020, and 9020
4	6200741	ABSORBER, SHOCK	1	Models: 3020, 4020, 5020, 7020, and 9020
5	6201674	SHUTTER	1	Models: 3020, 4020, 5020, 7020, and 9020
6	6217624	MAGNET	1	Models: 3020, 4020, 5020, 7020, and 9020
7	6200721	SPRING	1	Models: 3020, 4020, 5020, 7020, and 9020
8	6200502	MOUNT, LENS	1	Models: 3020, 4020, 5020, 7020, and 9020
9	6200691	SHAFT	1	Models: 3020, 4020, 5020, 7020, and 9020
10	4302381	SCREW	1	Models: 3020, 4020, 5020, 7020, and 9020
11	6200622	PLATE	1	Models: 3020, 4020, 5020, 7020, and 9020
12	6200531	SPRING	1	Models: 3020, 4020, 5020, 7020, and 9020
13	6201311	BAFFLE, LIGHT	1	Models: 4020, 5020, 7020, and 9020




A028_0026DC

Figure 5


Item	Part No.	Description	Qty.	Notes
1	6205061	COVER, PRISM	2	Models: 5020 and 9020
2	6150131	PRISM	2	Models: 5020 and 9020
3	6210854	BOARD, AF II	1	Models: 5020 and 9020
4	6205753	RETAINER AF III AY	1	Models: 5020 and 9020

Figure 6




A028_0025DC

Item	Part No.	Description	Qty.	Notes
1	4282851	SCREW	2	Models: 3020, 4020, 5020, 7020, and 9020
2	6217094	CAM AND SHUTTER SENSOR AY	1	Models: 3020, 4020, 5020, 7020, and 9020
3	6200354	PAD, PRESSURE	1	Models: 3020, 4020, 5020, 7020, and 9020
4	6201541	SPRING	1	Models: 3020, 4020, 5020, 7020, and 9020
5	6200381	LEVER	1	Models: 3020, 4020, 5020, 7020, and 9020
6	4302491	SCREW	2	Models: 3020, 4020, 5020, 7020, and 9020
7	6217584	MOTOR	1	Models: 3020, 4020, 5020, 7020, and 9020
8	6200281	SPRING	1	Models: 3020, 4020, 5020, 7020, and 9020
9	6200295	FRAME, MECHANISM	1	Models: 3020, 4020, 5020, 7020, and 9020
10	6200262	COVER, MECHANISM FRAME	1	Models: 3020, 4020, 5020, 7020, and 9020
11	4485810	WASHER	2	Models: 3020, 4020, 5020, 7020, and 9020
12	4282851	SCREW	2	Models: 3020, 4020, 5020, 7020, and 9020




A028_0024DC

Item	Part No.	Description	Qty.	Notes
1	6201491	SPRING	1	Models: 3020, 4020, 5020, 7020, and 9020
2	6200453	CAM	1	Models: 3020, 4020, 5020, 7020, and 9020
3	6200401	LIFTER, SIDE	1	Models: 3020, 4020, 5020, 7020, and 9020
4	6200371	SPRING	1	Models: 3020, 4020, 5020, 7020, and 9020
5	6200471	LEVER	1	Models: 3020, 4020, 5020, 7020, and 9020
6	6200271	LEVER, TRAY RELEASE	1	Models: 3020, 4020, 5020, 7020, and 9020
7	6200331	LEVER, SLIDE REGULATION	1	Models: 3020, 4020, 5020, 7020, and 9020
8	6200341	SPRING	1	Models: 3020, 4020, 5020, 7020, and 9020
9	4302421	SCREW	1	Models: 3020, 4020, 5020, 7020, and 9020




A028_0023EC

Item	Part No.	Description	Qty.	Notes
1	6210314	BOARD	1	Models: 3020, 4020, and 7020
	6210414	BOARD	1	Model 5020
	6210394	BOARD	1	Model 9020
2	6200953	LAMP HOUSING AY	1	Models: 3020, 4020, 5020, 7020, and 9020
3	4282921	SCREW	1	Models: 7020 and 9020
4	6217804	SOCKET	1	Models: 7020 and 9020
5	6207101	ADAPTER	1	Models: 7020 and 9020
6	4302421	SCREW	2	Models: 3020, 4020, 5020, 7020, and 9020
7	6200031	SHIELD, POWER SUPPLY	1	Models: 7020 and 9020
8	6210704	BOARD, POWER SUPPLY	1	Model 3020
	6210774	BOARD, POWER SUPPLY for SMD	1	Models: 4020, 5020, 7020, and 9020
9	4301921	SCREW	4	Models: 3020, 4020, 5020, 7020, and 9020
10	6217564	TRANSFORMER	1	Model 3020
	6217614	TRANSFORMER	1	Models: 4020, 5020, 7020, and 9020
	6217634	TRANSFORMER-Japan	1	Models: 3020, 4020, 5020, 7020, and 9020
11	4534441	WIRE, GROUND 280 mm (11 in.)	1	Models: 3020, 4020, 5020, 7020, and 9020




A028_0022EC

Item	Part No.	Description	Qty.	Notes
1	6217191	SINGLE SOCKET AY	1	Model 3020
	6217391	DUAL SOCKET AY	1	Models: 4020, 5020, 7020, and 9020
2	6217674	FAN	1	Models: 3020, 4020, 5020, 7020, and 9020
3	6200041	PAD, FOCUSING MOTOR RUBBER	1	Models: 3020, 4020, 5020, 7020, and 9020
4	6217344	MOTOR, FOCUS	1	Models: 3020, 4020, 5020, 7020, and 9020
5	6200481	SPRING	1	Models: 3020, 4020, 5020, 7020, and 9020
6	6205202	TIMER	1	Models: 5020 and 9020
7	6205212	TIMER	1	Models: 5020 and 9020




A028_0021DC

Item	Part No.	Description	Qty.	Notes
1	4535021	FUSE HOLDER AY	2	Models: 3020, 4020, 5020, 7020, and 9020
	4541051	FUSE, T1.25A	1	Models: 3020, 4020, 5020, 7020, and 9020
	4539891	FUSE, T1.25A-U.S. and Canada	1	Models: 7020 and 9020
2	4515691	FUSE, T2, A	1	Models: 3020, 4020, 5020, 7020, and 9020
	4541201	FUSE, T2, 8A-U.S. and Canada	1	Models: 7020 and 9020
	6202100	PLATE, BACK	1	Model 3020
	6205300	PLATE, BACK	1	Models: 4020 and 5020
	6207300	PLATE, BACK	1	Models: 7020 and 9020
	6207710	PLATE, BACK-Korea	1	Model 7020
3	6207901	PLATE, BACK-U.S., LABEL FUSE 2.8A	1	Models: 7020 and 9020
	6215061	SCREW	2 - 4	Models: 4020, 5020, 7020, and 9020
4	6210504	BOARD-BACK PANEL	1	Models: 4020 and 5020
5	6210554	BOARD-BACK PANEL	1	Models: 7020 and 9020
	6207321	COVER	1	Models: 7020 and 9020
6	4283671	SCREW	2	Models: 7020 and 9020




A028_0020DC

Item	Part No.	Description	Qty.	Notes
1	4513990	CORD, POWER-German	1	Models: 3020, 4020, 5020, 7020, and 9020
	6217861	CORD, POWER-Australia	1	Models: 3020, 4020, 5020, 7020, and 9020
	6217851	CORD, POWER-UK	1	Models: 3020, 4020, 5020, 7020, and 9020
	6004060	CORD, POWER-France	1	Models: 3020, 4020, 5020, 7020, and 9020
	6037200	CORD, POWER-China	1	Models: 3020, 4020, 5020, 7020, and 9020
	6051531	CORD, POWER-U.S. and Canada	1	Models: 7020 and 9020
2	6217024	SOCKET AND SWITCH AY	1	Models: 3020, 4020, 5020, 7020, and 9020
3	6217842	SOCKET AND SWITCH AY-Korea	1	Model 7020
	4282501	SCREW	1	Models: 3020, 4020, 5020, 7020, and 9020
4	4488121	WASHER	1	Models: 3020, 4020, 5020, 7020, and 9020
	4852712	NUT	1	Models: 3020, 4020, 5020, 7020, and 9020
	6217751	HOLDER, FUSE	1	Models: 3020, 4020, 5020, 7020, and 9020
5	6217231	SELECTOR, VOLTAGE-Europe	1	Models: 3020, 4020, 5020, 7020, and 9020
	6217241	SELECTOR, VOLTAGE-U.S. and Canada	1	Models: 7020 and 9020
	6217261	SELECTOR, VOLTAGE-Japan	1	Models: 3020, 4020, 5020, 7020, and 9020
6	4515691	FUSE, T2A, 220 - 240 V-Europe	1	Models: 3020, 4020, 5020, 7020, and 9020
	4534021	FUSE, T4A, 100 - 120 V-U.S. and Canada	1	Models: 7020 and 9020
	4535381	FUSE, T2A, 220 - 240 V-U.S. and Canada	1	Models: 7020 and 9020
7	4531821	FUSE, T4A, 110 - 120 V-Japan	1	Models: 3020, 4020, 5020, 7020, and 9020
	4302421	SCREW	2	Models: 4020, 5020, 7020, and 9020




A028_0019EC

Item	Part No.	Description	Qty.	Notes
1	6214394	MICROCONTROLLER, V 2.34	1	Model 3020
	6215144	MICROCONTROLLER, V 4.8	1	Model 4020
	6215154	MICROCONTROLLER, V 4.8	1	Model 5020
2	6251741	MICROCONTROLLER, V 4.7	1	Model 7020
	6215184	MICROCONTROLLER, V 4.7	1	Model 9020
	6210034	MASTER CIRCUIT BOARD AY	1	Model 3020
3	6210074	MASTER CIRCUIT BOARD AY for SMD	1	Models: 4020 and 7020
	6210094	MASTER CIRCUIT BOARD AY for SMD	1	Models: 5020 and 9020
	6202264	HOUSING, LOWER	1	Models: 3020, 4020, 5020, 7020, and 9020
4	4302361	SCREW	4	Models: 3020, 4020, 5020, 7020, and 9020
5	6200131	FOOT, RUBBER	1	Models: 3020, 4020, 5020, 7020, and 9020
6	6200141	BUFFER	2	Models: 3020, 4020, 5020, 7020, and 9020
7	6200061	KNOB, right	1	Models: 3020, 4020, 5020, 7020, and 9020
	6200081	KNOB, left Elevator	1	Models: 3020, 4020, 5020, 7020, and 9020
8	6200051	ELEVATOR, right	1	Models: 3020, 4020, 5020, 7020, and 9020
	6200071	ELEVATOR, left	1	Models: 3020, 4020, 5020, 7020, and 9020



A028_0018EC


Item	Part No.	Description	Qty.	Notes
1	6200091	FOOT, ELEVATOR	2	Models: 3020, 4020, 5020, 7020, and 9020
2	6203261	LABEL, RATING, STANDARD	1	Model 3020
	6204261	LABEL, RATING, STANDARD	1	Model 4020
	6205281	LABEL, RATING, STANDARD	1	Model 5020
	6207261	LABEL, RATING, STANDARD	1	Model 7020
	6207881	LABEL, RATING-U.S. and Canada	1	Model 7020
	6207691	LABEL, RATING-Korea	1	Model 7020
	6208061	LABEL, RATING, STANDARD	1	Model 9020
	6205861	LABEL, RATING-Japan	1	Model 5020
3	6208321	LABEL, RATING-Japan	1	Model 9020
	6208421	LABEL, RATING-U.S. and Canada	1	Model 9020
	4302421	SCREW	1	Models: 3020, 4020, 5020, 7020, and 9020
4	6200202	COVER	1	Models: 3020, 4020, 5020, 7020, and 9020
5	6201801	HANDLE	1	Models: 3020, 4020, 5020, 7020, and 9020
6	G9903835	SCREW, INSERT	-	Models: 3020, 4020, 5020, 7020, and 9020



A028_0017EC

Item	Part No.	Description	Qty.	Notes
1	4302531	SCREW	3	Models: 3020, 4020, 5020, 7020, and 9020
2	6201141	HOUSING, LAMP	1	Models: 3020, 4020, 5020, 7020, and 9020
3	6201361	LATCH, RELEASE	1	Models: 3020, 4020, 5020, 7020, and 9020
4	6201461	SPRING	1	Models: 3020, 4020, 5020, 7020, and 9020
5	6201381	LABEL, LAMP MODULE, single	1	Model 3020
	6205481	LABEL, LAMP MODULE, dual	1	Models: 4020, 5020, 7020, and 9020
6	6207771	LABEL, LAMP MODULE, dual-Korea	1	Model 7020
	6201352	PLATE, GRILL	1	Models: 3020, 4020, 5020, 7020, and 9020
	None	LAMP, 35h, 70h, and 200h	1, 2	Models: 3020, 4020, 5020, 7020, and 9020, Listed in the <i>Kodak</i> Price Catalog
8	6201101	EJECTOR	1,2	Models: 3020, 4020, 5020, 7020, and 9020
9	6217154	LAMP SOCKET AY, single	1	Model 3020
	6217204	LAMP SOCKET AY, dual	1	Models: 4020, 5020, 7020, and 9020
10	6201131	HOUSING, LAMP	1	Models: 3020, 4020, 5020, 7020, and 9020
11	4487440	CIRCLIP	1	Models: 3020, 4020, 5020, 7020, and 9020
12	4488121	WASHER	2	Models: 3020, 4020, 5020, 7020, and 9020

Figure 15




A028_0016EC

Item	Part No.	Description	Qty.	Notes
1	6217171	PLUG	1	Models: 3020, 4020, 5020, 7020, and 9020
2	6201752	LENS, CONDENSER for slide 24 x 36 mm	1	Models: 4020, 5020, 7020, and 9020
	6220335	LENS, CONDENSER for Superslide, 4 x 4 optional	1	Models: 4020, 5020, 7020, and 9020
3	6201211	CLIP	1	Models: 4020, 5020, 7020, and 9020
	6201731	CLIP, SUPERSLIDE, 4 X 4 optional	1	Models: 4020, 5020, 7020, and 9020
4	6201994	MIRROR	1	Models: 4020, 5020, 7020, and 9020
5	6201190	SPRING, black coated	1	Models: 4020, 5020, 7020, and 9020
6	6201180	HOLDER, MIRROR, black coated	1	Models: 4020, 5020, 7020, and 9020
7	6200361	SPRING	1	Model 3020
8	6205421	SPRING	1	Models: 4020, 5020, 7020, and 9020
9	6217134	MOTOR	1	Models: 4020, 5020, 7020, and 9020
10	6201111	PLATE, AIR, exhaust	1	Models: 4020, 5020, 7020, and 9020
11	6201941	LABEL, extra bright	1	Models: 4020, 5020, 7020, and 9020
- -	*	MODULE, complete single lamp	1	Listed in the <i>Kodak Price Catalog</i>
- -	**	MODULE, complete dual lamp	1	Listed in the <i>Kodak Price Catalog</i>

* CAT 718 4351

** CAT 718 4369




A028_0015DCA
A028_0015DC

Figure 16

Item	Part No.	Description	Qty.	Notes
1	6036312	PLATE	1	Accessory
2	6036331	SPRING	1	Accessory
3	6036321	LEVER	1	Accessory
4	None	TRAY, SLIDE	1	Accessory, Listed in the <i>Kodak Price Catalog</i>
5	6006100	COVER	1	Accessory
6	6036341	SPRING	3	Accessory


Figure 17 Kodak Ektapro CABLE REMOTE



A028_0014DCA
A028_0014DC


Figure 17

Item	Part No.	Description	Qty.	Notes
1	None	REMOTE, CABLE	-	Accessory, Listed in the Kodak Price Catalog
2	6220224	TOP	1	Accessory
3	6220134	BASE	1	Accessory
4	None	EXTENSION	-	Accessory, Listed in the Kodak Price Catalog

Figure 18 Kodak Ektapro IR REMOTE SYSTEM RA, RA / LP and IR REMOTE RECEIVER RAA028_0013DCA
A028_0013DC**Figure 18**

Item	Part No.	Description	Qty.	Notes
1	6220105	REMOTE, IR, for RA / LP	1	Accessory
	6220155	REMOTE, IR, for RA	1	Accessory
2	6220164	TOP, RA	1	Accessory
	6220114	TOP, RA / LP	1	Accessory
3	6220144	SLIDE COVER, for RA and RA / LP	1	Accessory
4	6220134	BASE, for RA and RA / LP	1	Accessory
5	6220364	COVER, front	1	Accessory
6	6220374	COVER, back	1	Accessory
7	None	RECEIVER, IR, REMOTE, for RA	1	Accessory, Listed in the Kodak Price Catalog
8	6220401	BATTERY CONTACT, long	1	Accessory
9	6220411	BATTER CONTACT, short	1	Accessory

Figure 19 Kodak Ektapro 7/12 PIN MODULE and 7/12 PIN ADAPTER CABLE




A028_0012DC

Figure 19

Item	Part No.	Description	Qty.	Notes
1	6207331	PLATE	1	Accessory
2	None	MODULE, 7 / 12 PIN	1	Accessory, Listed in the Kodak Price Catalog
3	None	CABLE, 7 / 12 PIN Adapter	1	Accessory, Listed in the Kodak Price Catalog
4	6220191	SWITCH	1	Accessory
5	6215061	SCREW	2	Accessory
	4488131	WASHER	2	Accessory
6	4539981	FUSE, T 0, 8A	2	Accessory

www.KodakParts.com
Figure 20 Kodak Ektapro TWIN SOCKET ADAPTER



A028_0011DCA
A028_0011DC

Figure 20

Item	Part No.	Description	Qty.	Notes
1	None	ADAPTER, TWIN SOCKET	-	Accessory, Listed in the <i>Kodak Price Catalog</i>
2	6220174	COVER, front	1	Accessory
3	6220184	COVER, back	1	Accessory
4	None	CABLE, CONNECTING, 2m	-	Accessory, Listed in the <i>Kodak Price Catalog</i>

Figure 21 CABLE AY and WIRES for the *Kodak Ektapro* PROJECTORS, Model 3010 - 9010


Figure 21

Item	Part No.	Description	Qty.	Notes
1	6217391	DUAL SOCKET AY, STANDARD-Japan, Korea	1	Models: 4020, 5020, 7020, and 9020
2	6217191	SINGLE SOCKET AY, STANDARD-Japan	1	Model 3020
3	6217591	CABLE AY	1	Models: 3020, 4020, 5020, 7020, 9020
4	6217471	CABLE AY	1	Models: 3020, 4020, 5020, 7020, 9020
5	4534411	WIRE	1	Models: 3020, 4020, 5020, 7020, 9020
6	4534421	WIRE	1	Models: 3020, 4020, 5020, 7020, 9020

NOTE

For the KODAK EKTAPRO Carrying Case and for the KODAK EKTAPRO SELECT Projections Lenses no parts are planned. Possible repairs of the SELECT Projections Lenses should be settled via KODAK AG.

Exception Sleeve PN G9903955



Manufacturer of Lenses:
Docter-Optics GmbH
Prof. Erich Schott Str. 1 - 3
35641 Schöffengrund

Phone: 0049-6445-6090
FAX: 0049-6445-6090-5

A028_0010HC

Figure 22

Item	Part No.	Description	Qty.	Notes
--	G9903955	SLEEVE, EXCEPTION	1	

Section 2: Alphabetical Index

Alphabetical Index

Part No.	Description	Figure No.
6200741	ABSORBER, SHOCK	4
6207101	ADAPTER	8
None	ADAPTER, TWIN SOCKET	20
6201311	BAFFLE, LIGHT	4
6220134	BASE	17
6220134	BASE, for RA and RA / LP	18
6220411	BATTER CONTACT, short	18
6220401	BATTERY CONTACT, long	18
6210314	BOARD	8
6210394	BOARD	8
6210414	BOARD	8
6210854	BOARD, AF II	5
6210774	BOARD, POWER SUPPLY for SMD	8
6210704	BOARD, POWER SUPPLY	8
6210504	BOARD-BACK PANEL	10
6210554	BOARD-BACK PANEL	10
6200141	BUFFER	12
6202181	BUTTON	2
6202141	BUTTON, FORWARD FOCUS	2
6202161	BUTTON, FORWARD	2
6202131	BUTTON, REVERSE FOCUS	2
6202151	BUTTON, REVERSE	2
6202171	BUTTON, STAND-BY	2
6202191	BUTTON, TRAY SWITCH	2
6217471	CABLE AY	21
6217591	CABLE AY	21
None	CABLE, 7 / 12 PIN Adapter	19
None	CABLE, CONNECTING, 2m	20
6217094	CAM AND SHUTTER SENSOR AY	6
6200453	CAM	7
4487440	CIRCLIP	14
6201211	CLIP	15
6201871	CLIP	3
6201731	CLIP, SUPERSLIDE, 4 X 4 optional	15
6217861	CORD, POWER-Australia	11
6037200	CORD, POWER-China	11
6004060	CORD, POWER-France	11
4513990	CORD, POWER-German	11
6051531	CORD, POWER-U.S. and Canada	11
6217851	CORD, POWER-UK	11
6006100	COVER	16
6200202	COVER	13
6207321	COVER	10
6220184	COVER, back	20
6220374	COVER, back	18
6220174	COVER, front	20

Part No.	Description	Figure No.
6220364	COVER, front	18
6200262	COVER, MECHANISM FRAME	6
6205061	COVER, PRISM	5
6201881	DISK, CODER Serial No. 118 500 and above	3
6217391	DUAL SOCKET AY	9
6217391	DUAL SOCKET AY, STANDARD-Japan, Korea	21
6201861	ECCENTRIC	3
6201101	EJECTOR	14
6200071	ELEVATOR, left	12
6200051	ELEVATOR, right	12
None	EXTENSION	17
6217674	FAN	9
6200091	FOOT, ELEVATOR	13
6200131	FOOT, RUBBER	12
6200295	FRAME, MECHANISM	6
4535021	FUSE HOLDER AY	10
4539981	FUSE, T 0, 8A	19
4541051	FUSE, T1.25A	10
4539891	FUSE, T1.25A-U.S. and Canada	10
4541201	FUSE, T2, 8A-U.S. and Canada	10
4515691	FUSE, T2, A	10
4515691	FUSE, T2A, 220 - 240 V-Europe	11
4535381	FUSE, T2A, 220 - 240 V-U.S. and Canada	11
4534021	FUSE, T4A, 100 - 120 V-U.S. and Canada	11
4531821	FUSE, T4A, 110 - 120 V-Japan	11
6201801	HANDLE	13
6217751	HOLDER, FUSE	11
6201180	HOLDER, MIRROR, black coated	15
6200804	HOUSING, CENTER-with CLIP	3
6201131	HOUSING, LAMP	14
6201141	HOUSING, LAMP	14
6202264	HOUSING, LOWER	12
6202254	HOUSING, UPPER	1
6200811	INDICATOR, FOCUS	3
6200701	KNOB	1
6200081	KNOB, left Elevator	12
6200061	KNOB, right	12
6201941	LABEL, extra bright	15
6205481	LABEL, LAMP MODULE, dual	14
6207771	LABEL, LAMP MODULE, dual-Korea	14
6201381	LABEL, LAMP MODULE, single	14
4901411	LABEL, MODEL	1
6203031	LABEL, MODEL	1
6204022	LABEL, MODEL	1
6205022	LABEL, MODEL	1
6207022	LABEL, MODEL	1
6209022	LABEL, MODEL	1
6203261	LABEL, RATING, STANDARD	13

Part No.	Description	Figure No.
6204261	LABEL, RATING, STANDARD	13
6205281	LABEL, RATING, STANDARD	13
6207261	LABEL, RATING, STANDARD	13
6208061	LABEL, RATING, STANDARD	13
6205861	LABEL, RATING-Japan	13
6208321	LABEL, RATING-Japan	13
6207691	LABEL, RATING-Korea	13
6207881	LABEL, RATING-U.S. and Canada	13
6208421	LABEL, RATING-U.S. and Canada	13
6200953	LAMP HOUSING AY	8
6217204	LAMP SOCKET AY, dual	14
6217154	LAMP SOCKET AY, single	14
None	LAMP, 35h, 70h, and 200h	14
6200922	LATCH	3
6201361	LATCH, RELEASE	14
6201752	LENS, CONDENSER for slide 24 x 36 mm	15
6220335	LENS, CONDENSER for Superslide, 4 x 4 optional	15
6036321	LEVER	16
6200381	LEVER	6
6200471	LEVER	7
6200331	LEVER, SLIDE REGULATION	7
6200271	LEVER, TRAY RELEASE	7
6201521	LEVER, ZERO-new style	3
6200401	LIFTER, SIDE	7
6217624	MAGNET	4
6210074	MASTER CIRCUIT BOARD AY for SMD	12
6210094	MASTER CIRCUIT BOARD AY for SMD	12
6210034	MASTER CIRCUIT BOARD AY	12
6214394	MICROCONTROLLER, V 2.34	12
6215184	MICROCONTROLLER, V 4.7	12
6251741	MICROCONTROLLER, V 4.7	12
6215144	MICROCONTROLLER, V 4.8	12
6215154	MICROCONTROLLER, V 4.8	12
6201994	MIRROR	15
None	MODULE, 7 / 12 PIN	19
**	MODULE, complete dual lamp	15
*	MODULE, complete single lamp	15
6217134	MOTOR	15
6217364	MOTOR	3
6217584	MOTOR	6
6217344	MOTOR, FOCUS	9
6200502	MOUNT, LENS	4
4852712	NUT	11
6200041	PAD, FOCUSING MOTOR RUBBER	9
6200354	PAD, PRESSURE	6
6210824	PCB, TRAY, MOTION	3
6036312	PLATE	16
6200622	PLATE	4

Part No.	Description	Figure No.
6207331	PLATE	19
6201111	PLATE, AIR, exhaust	15
6202100	PLATE, BACK	10
6205300	PLATE, BACK	10
6207300	PLATE, BACK	10
6207710	PLATE, BACK-Korea	10
6207901	PLATE, BACK-U.S., LABEL FUSE 2.8A	10
6202062	PLATE, COVER	2
6202071	PLATE, COVER	2
6205102	PLATE, COVER	2
6208102	PLATE, COVER	2
6207722	PLATE, COVER-Korea	2
6201352	PLATE, GRILL	14
6217171	PLUG	15
6150131	PRISM	5
None	RECEIVER, IR, REMOTE, for RA	18
None	REMOTE, CABLE	17
6220105	REMOTE, IR, for RA / LP	18
6220155	REMOTE, IR, for RA	18
6205753	RETAINER AF III AY	5
6200911	RETAINER	3
6200751	RETAINER, AF	4
6200824	RING, DRIVE	3
6200931	ROLLER	3
6200871	ROLLER, BEARING	3
4719391	ROLLER, SHAFT	3
4282501	SCREW	11
4282851	SCREW	6
4282921	SCREW	8
4283671	SCREW	10
4301881	SCREW	4
4301911	SCREW	3
4301921	SCREW	8
4302361	SCREW	3, 12
4302381	SCREW	4
4302411	SCREW	3
4302421	SCREW	1, 3, 7, 8, 11, 13
4302491	SCREW	6
4302531	SCREW	14
4302541	SCREW	4
6215061	SCREW	10, 19
G9903835	SCREW, INSERT	13
6217231	SELECTOR, VOLTAGE-Europe	11
6217261	SELECTOR, VOLTAGE-Japan	11
6217241	SELECTOR, VOLTAGE-U.S. and Canada	11
6200691	SHAFT	4
6200031	SHIELD, POWER SUPPLY	8
6201674	SHUTTER	4

Part No.	Description	Figure No.
6217191	SINGLE SOCKET AY	9
6217191	SINGLE SOCKET AY, STANDARD-Japan	21
G9903955	SLEEVE, EXCEPTION	22
6220144	SLIDE COVER, for RA and RA / LP	18
6217024	SOCKET AND SWITCH AY	11
6217842	SOCKET AND SWITCH AY-Korea	11
6217804	SOCKET	8
6036331	SPRING	16
6036341	SPRING	16
6200281	SPRING	6
6200341	SPRING	7
6200361	SPRING	15
6200371	SPRING	7
6200481	SPRING	9
6200531	SPRING	4
6200721	SPRING	4
6201461	SPRING	14
6201491	SPRING	7
6201541	SPRING	6
6205421	SPRING	15
6201190	SPRING, black coated	15
6200631	SPRING, new style	3
6220191	SWITCH	19
6205202	TIMER	9
6205212	TIMER	9
6220224	TOP	17
6220114	TOP, RA / LP	18
6220164	TOP, RA	18
6217564	TRANSFORMER	8
6217614	TRANSFORMER	8
6217634	TRANSFORMER-Japan	8
None	TRAY, SLIDE	16
6205451	WARNING LABEL	3
4485810	WASHER	6
4488121	WASHER	11, 14
4488131	WASHER	19
6200861	WHEEL, GEAR	3
6200971	WHEEL, GEAR	3
6202031	WINDOW	1
4534411	WIRE	21
4534421	WIRE	21
4534441	WIRE, GROUND 280 mm (11 in.)	8

Section 3: Numerical Index**Numerical Index**

Part No.	Description	Figure No.
*	MODULE, complete single lamp	15
**	MODULE, complete dual lamp	15
4282501	SCREW	11
4282851	SCREW	6
4282921	SCREW	8
4283671	SCREW	10
4301881	SCREW	4
4301911	SCREW	3
4301921	SCREW	8
4302361	SCREW	3, 12
4302381	SCREW	4
4302411	SCREW	3
4302421	SCREW	1, 3, 7, 8, 11, 13
4302491	SCREW	6
4302531	SCREW	14
4302541	SCREW	4
4485810	WASHER	6
4487440	CIRCLIP	14
4488121	WASHER	11, 14
4488131	WASHER	19
4513990	CORD, POWER-German	11
4515691	FUSE, T2, A	10
4515691	FUSE, T2A, 220 - 240 V-Europe	11
4531821	FUSE, T4A, 110 - 120 V-Japan	11
4534021	FUSE, T4A, 100 - 120 V-U.S. and Canada	11
4534411	WIRE	21
4534421	WIRE	21
4534441	WIRE, GROUND 280 mm (11 in.)	8
4535021	FUSE HOLDER AY	10
4535381	FUSE, T2A, 220 - 240 V-U.S. and Canada	11
4539891	FUSE, T1.25A-U.S. and Canada	10
4539981	FUSE, T 0, 8A	19
4541051	FUSE, T1.25A	10
4541201	FUSE, T2, 8A-U.S. and Canada	10
4719391	ROLLER, SHAFT	3
4852712	NUT	11
4901411	LABEL, MODEL	1
6004060	CORD, POWER-France	11
6006100	COVER	16
6036312	PLATE	16
6036321	LEVER	16
6036331	SPRING	16
6036341	SPRING	16
6037200	CORD, POWER-China	11
6051531	CORD, POWER-U.S. and Canada	11
6150131	PRISM	5

Part No.	Description	Figure No.
6200031	SHIELD, POWER SUPPLY	8
6200041	PAD, FOCUSING MOTOR RUBBER	9
6200051	ELEVATOR, right	12
6200061	KNOB, right	12
6200071	ELEVATOR, left	12
6200081	KNOB, left Elevator	12
6200091	FOOT, ELEVATOR	13
6200131	FOOT, RUBBER	12
6200141	BUFFER	12
6200202	COVER	13
6200262	COVER, MECHANISM FRAME	6
6200271	LEVER, TRAY RELEASE	7
6200281	SPRING	6
6200295	FRAME, MECHANISM	6
6200331	LEVER, SLIDE REGULATION	7
6200341	SPRING	7
6200354	PAD, PRESSURE	6
6200361	SPRING	15
6200371	SPRING	7
6200381	LEVER	6
6200401	LIFTER, SIDE	7
6200453	CAM	7
6200471	LEVER	7
6200481	SPRING	9
6200502	MOUNT, LENS	4
6200531	SPRING	4
6200622	PLATE	4
6200631	SPRING, new style	3
6200691	SHAFT	4
6200701	KNOB	1
6200721	SPRING	4
6200741	ABSORBER, SHOCK	4
6200751	RETAINER, AF	4
6200804	HOUSING, CENTER-with CLIP	3
6200811	INDICATOR, FOCUS	3
6200824	RING, DRIVE	3
6200861	WHEEL, GEAR	3
6200871	ROLLER, BEARING	3
6200911	RETAINER	3
6200922	LATCH	3
6200931	ROLLER	3
6200953	LAMP HOUSING AY	8
6200971	WHEEL, GEAR	3
6201101	EJECTOR	14
6201111	PLATE, AIR, exhaust	15
6201131	HOUSING, LAMP	14
6201141	HOUSING, LAMP	14
6201180	HOLDER, MIRROR, black coated	15

Part No.	Description	Figure No.
6201190	SPRING, black coated	15
6201211	CLIP	15
6201311	BAFFLE, LIGHT	4
6201352	PLATE, GRILL	14
6201361	LATCH, RELEASE	14
6201381	LABEL, LAMP MODULE, single	14
6201461	SPRING	14
6201491	SPRING	7
6201521	LEVER, ZERO-new style	3
6201541	SPRING	6
6201674	SHUTTER	4
6201731	CLIP, SUPERSLIDE, 4 X 4 optional	15
6201752	LENS, CONDENSER for slide 24 x 36 mm	15
6201801	HANDLE	13
6201861	ECCENTRIC	3
6201871	CLIP	3
6201881	DISK, CODER Serial No. 118 500 and above	3
6201941	LABEL, extra bright	15
6201994	MIRROR	15
6202031	WINDOW	1
6202062	PLATE, COVER	2
6202071	PLATE, COVER	2
6202100	PLATE, BACK	10
6202131	BUTTON, REVERSE FOCUS	2
6202141	BUTTON, FORWARD FOCUS	2
6202151	BUTTON, REVERSE	2
6202161	BUTTON, FORWARD	2
6202171	BUTTON, STAND-BY	2
6202181	BUTTON	2
6202191	BUTTON, TRAY SWITCH	2
6202254	HOUSING, UPPER	1
6202264	HOUSING, LOWER	12
6203031	LABEL, MODEL	1
6203261	LABEL, RATING, STANDARD	13
6204022	LABEL, MODEL	1
6204261	LABEL, RATING, STANDARD	13
6205022	LABEL, MODEL	1
6205061	COVER, PRISM	5
6205102	PLATE, COVER	2
6205202	TIMER	9
6205212	TIMER	9
6205281	LABEL, RATING, STANDARD	13
6205300	PLATE, BACK	10
6205421	SPRING	15
6205451	WARNING LABEL	3
6205481	LABEL, LAMP MODULE, dual	14
6205753	RETAINER AF III AY	5
6205861	LABEL, RATING-Japan	13

Part No.	Description	Figure No.
6207022	LABEL, MODEL	1
6207101	ADAPTER	8
6207261	LABEL, RATING, STANDARD	13
6207300	PLATE, BACK	10
6207321	COVER	10
6207331	PLATE	19
6207691	LABEL, RATING-Korea	13
6207710	PLATE, BACK-Korea	10
6207722	PLATE, COVER-Korea	2
6207771	LABEL, LAMP MODULE, dual-Korea	14
6207881	LABEL, RATING-U.S. and Canada	13
6207901	PLATE, BACK-U.S., LABEL FUSE 2.8A	10
6208061	LABEL, RATING, STANDARD	13
6208102	PLATE, COVER	2
6208321	LABEL, RATING-Japan	13
6208421	LABEL, RATING-U.S. and Canada	13
6209022	LABEL, MODEL	1
6210034	MASTER CIRCUIT BOARD AY	12
6210074	MASTER CIRCUIT BOARD AY for SMD	12
6210094	MASTER CIRCUIT BOARD AY for SMD	12
6210314	BOARD	8
6210394	BOARD	8
6210414	BOARD	8
6210504	BOARD-BACK PANEL	10
6210554	BOARD-BACK PANEL	10
6210704	BOARD, POWER SUPPLY	8
6210774	BOARD, POWER SUPPLY for SMD	8
6210824	PCB, TRAY, MOTION	3
6210854	BOARD, AF II	5
6214394	MICROCONTROLLER, V 2.34	12
6215061	SCREW	10, 19
6215144	MICROCONTROLLER, V 4.8	12
6215154	MICROCONTROLLER, V 4.8	12
6215184	MICROCONTROLLER, V 4.7	12
6217024	SOCKET AND SWITCH AY	11
6217094	CAM AND SHUTTER SENSOR AY	6
6217134	MOTOR	15
6217154	LAMP SOCKET AY, single	14
6217171	PLUG	15
6217191	SINGLE SOCKET AY	9
6217191	SINGLE SOCKET AY, STANDARD-Japan	21
6217204	LAMP SOCKET AY, dual	14
6217231	SELECTOR, VOLTAGE-Europe	11
6217241	SELECTOR, VOLTAGE-U.S. and Canada	11
6217261	SELECTOR, VOLTAGE-Japan	11
6217344	MOTOR, FOCUS	9
6217364	MOTOR	3
6217391	DUAL SOCKET AY	9

Part No.	Description	Figure No.
6217391	DUAL SOCKET AY, STANDARD-Japan, Korea	21
6217471	CABLE AY	21
6217564	TRANSFORMER	8
6217584	MOTOR	6
6217591	CABLE AY	21
6217614	TRANSFORMER	8
6217624	MAGNET	4
6217634	TRANSFORMER-Japan	8
6217674	FAN	9
6217751	HOLDER, FUSE	11
6217804	SOCKET	8
6217842	SOCKET AND SWITCH AY-Korea	11
6217851	CORD, POWER-UK	11
6217861	CORD, POWER-Australia	11
6220105	REMOTE, IR, for RA / LP	18
6220114	TOP, RA / LP	18
6220134	BASE	17
6220134	BASE, for RA and RA / LP	18
6220144	SLIDE COVER, for RA and RA / LP	18
6220155	REMOTE, IR, for RA	18
6220164	TOP, RA	18
6220174	COVER, front	20
6220184	COVER, back	20
6220191	SWITCH	19
6220224	TOP	17
6220335	LENS, CONDENSER for Superslide, 4 x 4 optional	15
6220364	COVER, front	18
6220374	COVER, back	18
6220401	BATTERY CONTACT, long	18
6220411	BATTERY CONTACT, short	18
6251741	MICROCONTROLLER, V 4.7	12
G9903835	SCREW, INSERT	13
G9903955	SLEEVE, EXCEPTION	22
None	ADAPTER, TWIN SOCKET	20
None	CABLE, 7 / 12 PIN Adapter	19
None	CABLE, CONNECTING, 2m	20
None	EXTENSION	17
None	LAMP, 35h, 70h, and 200h	14
None	MODULE, 7 / 12 PIN	19
None	RECEIVER, IR, REMOTE, for RA	18
None	REMOTE, CABLE	17
None	TRAY, SLIDE	16

This page is intentionally blank.

Compliments of:
www.KodakParts.com

Kodak and Ektapro are trademarks.

Printed in U.S.A. • ip2547_1.fm

EASTMAN KODAK COMPANY
Rochester, NY 14650

Kodak Service & Support