


Canon

COMMAND BACK E1

C50-7041

**PARTS
CATALOG**

CANON COMMAND BACK EI



PARTS LIST

Pg.1

REF.NO.C50-7041

Report.No.	NEW PARTS NO.	CLASS	QTY	DESCRIPTION
	CA1-5074-000	E	1	SCREW, STOPPER
	CA1-5826-000	D	1	SHAFT, HINGE
	CA1-6522-000	E	1	CLAW, BACK COVER
	CA1-6525-000	E	1	PLATE, SPRING
	CA4-4228-000	E	1	MAGNET, PERMANENT
	CA4-4232-000	D	1	COVER, SAFETY
	CA4-4236-000	E	1	COVER, LCD 1
	CA4-4237-000	E	1	SHIELD, LIGHT
	CA4-4238-000	E	1	SHIELD, LIGHT
	CA4-4241-000	C	1	CONTACT, RUBBER
	CA4-4390-000	E	1	PIN, CONTACT
	CA4-4393-000	E	1	PLATE, SHIELD
	CA4-4395-000	E	1	INSULATOR
	CA4-4429-000	C	1	COVER, BATTERY
	CA4-4432-000	E	2	SHAFT
	CA4-4434-000	E	5	PIN, CONTACT
	CA4-5393-000	E	1	SEAL, MELTI-LINGUAL
	CF4-0672-000	D	1	INNER COVER LCD
	CH2-1888-000	E	2	CONNECTOR, LCD 1
	CH2-1889-000	E	2	CONNECTOR, LCD 2
	CH5-0014-000	E	1	LCD2
	CH5-0019-000	E	1	LCD1
	CN5-5071-000	E	1	MIRROR
	CS1-5696-000	D	1	SPRING, COIL
	CS1-5765-000	C	1	SPRING, CONTACT
	CS1-5766-000	D	1	SPRING, GND CONTACT
	CS1-5866-000	D	1	SPRING, SWITCH COVER
	CS1-7562-000	C	1	HOLDER, FILM MAGAZINE
	CS2-5201-000	D	5	SPRING, COIL
AS-531	CY1-4148-000	D	1	PLATE, PRESSURE
	CY1-4194-000	D	1	COVER, BACK
	CY1-4195-000	D	1	MAIN PCB ASS'Y
	X99-0442-000		3	SCREW
	X99-0470-000		1	NUT
	X99-0505-000		5	SCREW
AS-531	X99-0613-000		2	SCREW
AS-548	X99-0626-000		2	SCREW
	X99-0685-000		3	SCREW
	XA1-1170-227		2	SCREW
	XA1-7170-407		1	SCREW