



DATE BACK DB-E2

C51-8051

PARTS CATALOG

Exploded view diagram of a mechanical assembly, likely a control panel or electronic chassis. The diagram shows the main chassis and various sub-assemblies and components, including:

- Top Left:** CB4-0428 (Panel/cover), CB4-0430 (Bracket), (CB1-6745) (Screw), (CS2-5857-000) (See detail) (Bracket).
- Top Center:** CBI-6736 (Circular component), CBI-6732 (Screw), CB4-0424 (Bracket), CBI-7755 (Screw).
- Top Right:** CBI-6725 (Bracket), CBI-6735 (Bracket), CAI-6522 (Bracket), X99-0573_{x2} (Screw), CAI-6525 (Bracket), XA4-9170-307 (Bracket).
- Center:** CYI-4271 (Bracket), CB4-0425 (Bracket), CBI-7755 (Screw), CB4-0429 (Bracket), CH2-5111 (Bracket), AS-605 (Bracket), CYI-4289 (Bracket), CH4-1036 (Bracket), CBI-1927 (Bracket), CBI-1926 (Bracket), XDI-1103-616 (Bracket), CBI-2678 (Bracket).
- Bottom Left:** XG8-1100-591 (Bracket), CS2-5887-000 (See detail) (Bracket), CBI-6734 (Bracket), XA4-9170-457 (Bracket), X99-0470 (Bracket), CBI-7789 (Bracket), CB4-0422 (Bracket), CBI-7778 (Bracket), X99-0573 (Screw), CS2-6966 (Bracket), CBI-1928 (Bracket), CBI-0183 (Bracket).
- Bottom Center:** XA4-9170-357 (Bracket), X99-0573 (Screw), CHI-1469 (Bracket), XA4-9170-307 (Bracket), CY3-1053 (Bracket), CBI-7775 (Bracket), X99-0467_{x4} (Screw), CS2-3233 (Bracket), XA1-7170-307 (Bracket).
- Bottom Right:** CH2-5111 (Bracket), CBI-1927 (Bracket), CBI-1926 (Bracket), XDI-1103-616 (Bracket), CBI-2678 (Bracket), CBI-3787 (Bracket), CB4-0497 (Bracket), CB4-0427 (Bracket), CFI-2715 (Bracket).

CS2-5887-000 detail

010	267 g
020	241 g
030	207 g

PARTS LIST

Pg1

C51-8051

Report.No.	NEW	PART NO.	CLASS	QTY	DESCRIPTION
		CA1-5074-000	E	1	SCREW, STOPPER
		CA1-6522-000	E	1	CLAW, BACK COVER
		CA1-6525-000	E	1	PLATE, SPRING
		CB1-0183-000	D	1	ROLLER-1, BACK COVER GUIDE
		CB1-1926-000	E	1	DETENT, DIAL
		CB1-1927-000	E	1	CONTACT, DIAL LOCK SWITCH
		CB1-1928-000	E	1	HOLDER, ROLLER
		CB1-2678-000	F	1	SCREW
		CB1-3787-000	E	1	SPRING, CARTRIDGE
		CB1-6725-000	D	1	GLASS, ÇcÇw WINDOW
		CB1-6732-000	F	1	LEVER, BACK DIAL SW
		CB1-6734-000	F	1	HOLDER, CLICK
		CB1-6735-000	E	1	SHIELD, LIGHT DX
		CB1-6736-000	E	1	BACK COVER DIAL
		CB1-6745-000	E	1	SHAFT, HINGE
		CB1-7755-000		2	SCREW
		CB1-7775-000		1	SCREW
		CB1-7778-000		1	SCREW
		CB1-7789-000		1	SCREW
		CB4-0422-000	E	1	COVER, INNER QD
		CB4-0423-000	E	1	COVER, BATTERY
		CB4-0424-000	E	1	CONTACT, QD+
		CB4-0425-000	E	1	CONTACT, QD-
		CB4-0426-000	D	1	PLATE, SHIELD
		CB4-0427-000	E	1	PLATE, LAG
		CB4-0428-000	E	1	RUBBER, QD
		CB4-0429-000	F	1	SHIELD, LIGHT DATE FLAME
		CB4-0430-000	E	1	TAPE, QD RUBBER
		CB4-0497-000		1	SCREW
		CF1-2715-000	D	1	PLATE, PRESSURE
		CH1-1469-000	D	1	BACK DIAL P.C.B.
		CH2-5111-000	E	1	SWITCH, DATE
		CH4-1036-000	E	1	DATE MODULE UNIT
		CS2-3233-000	E	1	SHAFT, ROLLER HOLDER
		CS2-5857-000(010)	F	1	SPRING, COIL
		CS2-5857-000(020)	F	1	SPRING, COIL
		CS2-5887-000(010)	F	1	SPRING, COIL
		CS2-5887-000(020)	F	1	SPRING, COIL
		CS2-5887-000(030)	F	1	SPRING, COIL
		CS2-6966-000	E	1	SPRING, ROLLER
		CY1-4271-000	E	1	COVER, BACK
		CY1-4272-000	E	1	PIN, CONTACTS ASSY
AS-605		CY1-4289-000	D	1	BP MODULE UNIT
		CY3-1053-000	E	1	CONTACT, DIAL ASSY
		X99-0467-000		4	SCREW, CROSS-RECESS, PH
		X99-0470-000		1	NUT
		X99-0573-000		4	SCREW, CROSS-RECESS, PH
		XA1-7170-307		1	SCREW
		XA4-9170-307		2	SCREW, CROSS-RECESS, PH
		XA4-9170-357		1	SCREW, CROSS-RECESS, PH
		XA4-9170-457		1	SCREW, CROSS-RECESS, PH
		XD1-1103-616		1	WASHAR
		XG8-1100-591		1	BOAL, SHEEL