



EOS 3000 QD(JPN)	REF.NO. C12-8381
EOS 3000	C12-8386
EOS 3000 QD	C12-8387
EOS 88	C12-8388
EOS 88 QD	C12-8389

PARTS CATALOG

CANON

EOS 3000 QD (JPN)

EOS 3000

EOS 3000 QD

EOS 88

EOS 88 QD


REF. C12-8381

C12-8386

C12-8387

C12-8388

C12-8389



PARTS LIST

REF.No.C12-8381
 C12-8386,87
 C12-8388,89

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CA1-9427-000		4	SCREW,
	CB1-0282-000		2	SCREW,
	CB1-3398-000		1	SCREW,
	CB1-3401-000	C	1	GRIP
	CB1-3408-000	B	1	CAP, REMOTE
	CB1-3462-000	C	1	BUTTON, EXPOSURE
	CB1-3463-000	C	1	BUTTON, AE LOCK
	CB1-3789-000		1	SCREW,
	CB1-8331-000	C	1	BUTTON, RED EYE
	CB1-8332-000	C	1	BUTTON, SELF-TIMER
	CF1-2886-000	C	1	COVER ASS'Y, BATTERY
	CG1-3597-000	C	1	COVER ASS'Y, TOP
	CG1-3598-000	C	1	COVER ASS'Y, FRONT(88)
	CG1-3661-000	C	1	COVER ASS'Y, FRONT(88 QD)
	CG1-3662-000	C	1	COVER ASS'Y, FRONT(3000)
	CG1-3663-000	C	1	COVER ASS'Y, FRONT(3000 QD)
	CH2-5142-000	D	1	CONTACT, RUBBER
	CH2-5253-000	D	1	CONTACT, RUBBER
	XA4-9170-457		3	SCREW,

CANON

EOS 3000 QD (JPN)

EOS 3000

EOS 3000 QD

EOS 88

EOS 88 QD


REF. C12-8381

C12-8386

C12-8387

C12-8388

C12-8389



PARTS LIST

REF.No.C12-8381
C12-8386,87
C12-8388,89

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CA1-9427-000		6	SCREW,
	CB1-3350-000	C	1	COVER, LATCH
	CB1-3353-000	D	1	LUG, NECKSTRAP (LEFT)
	CB1-3367-000	D	1	HINGE, BACK COVER
	CB1-3399-000		1	SCREW,
	CB1-3409-000	D	1	LUG, NECKSTRAP (RIGHT)
	CB1-3470-000		1	SCREW,
	CB1-3788-000	D	1	SPRING, PRESSURE PLATE
	CB1-3789-000		1	SCREW,
	CB1-4757-000	D	1	PLATE, PRESSURE
	CF1-2887-000	D	1	LEVER, LATCH
	CF1-2888-000	D	1	CONTACT, MODE
	CF1-2889-000	D	1	FORK ASS'Y
	CG1-1386-000	D	1	COVER ASS'Y, BACK (QD)
	CG1-1397-000	D	1	MODE SWITCH BASE UNIT
	CG1-1507-000	D	1	COVER ASS'Y, BACK (NON-QD)
	CS2-0974-000	D	1	GEAR, REWIND 1
	CS2-0975-000	D	2	GEAR, REWIND 2
	CS2-0976-000	D	1	GEAR, REWIND 3
	CS2-5507-050	D	1	SPRING, BACK COVER LATCH
	CY3-1001-000	C	1	COVER, BASE
	CY3-1003-000	C	1	COVER, BASE (GENERIC)
	X71-9749-000	E	1	G RING
	XA4-9170-407		2	SCREW,
	XA4-9200-457		2	SCREW,

CANON

EOS 3000 QD (JPN)

EOS 3000

EOS 3000 QD

EOS 88

EOS 88 QD


REF. C12-8381

C12-8386

C12-8387

C12-8388

C12-8389



PARTS LIST

REF.No.C12-8381
 C12-8386,87
 C12-8388,89

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CA1-8666-050	C	1	BASE, ACC. SHOE
	CA1-9328-000	C	1	SPRING, PLATE
	CB1-3378-000	D	1	CONTACT, POP-END 1
	CB1-3379-000	D	1	CONTACT, POP-END 2
	CB1-3380-000	D	1	BASE, POP-END SWITCH
	CB1-3381-000	D	1	PIN, POP-END SWITCH
	CB1-3390-000	D	1	SHOE, ACCESSORY
	CB1-6461-000	D	1	PANEL, FLASH
	CB1-6469-000	D	1	BUTTON, RELEASE
	CB1-6483-000	D	1	CLICK SPRING, MODE DIAL
	CB1-8321-000	D	1	COVER, TOP
	CB1-8323-000	C	1	COVER, FLASH (SILVER)
	CB1-8325-000	D	1	WINDOW, OUTSIDE LCD
	CB1-8326-000	D	1	TAPE, DOUBLE-SIDED
	CB1-8327-000	D	1	DIAL, MODE
	CB1-8328-000	D	1	SHAFT, ST STOPPER
	CB1-8329-000	D	1	SCREW, SPRING HANGER
	CB1-8330-000	D	1	HOLDER, SPRING
	CG1-1394-000	D	1	FPC ASS'Y, TOP
	CS2-3301-000	D	2	SCREW,
	CS2-5656-000	D	1	SPRING, COIL
	CS3-6112-000	D	1	SPRING, POP UP
	CY3-1132-000	C	1	FLASH HEAD UNIT
	X99-0685-000		1	SCREW,
	XA1-3170-507		4	SCREW,
	XA4-6170-307		1	SCREW,
	XA4-9170-307		1	SCREW,
	XA4-9170-459		2	SCREW,
	XD2-1100-132		1	E RING

CANON

EOS 3000 QD (JPN)

EOS 3000

EOS 3000 QD

EOS 88

EOS 88 QD


REF. C12-8381

C12-8386

C12-8387

C12-8388

C12-8389



PARTS LIST

REF.No.C12-8381
 C12-8386,87
 C12-8388,89

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB1-1173-000	D	1	CUSHION, FOAM RUBBER
	CB1-3402-000	D	1	COVER, HINGE
	CB1-3403-000	D	1	COVER, DATE CONTACT
	CB1-3421-000		2	SCREW,
	CB1-3466-000	D	1	CASE, OUTSIDE LCD
	CB1-3467-000	D	1	HOLDER, OUTSIDE LCD
	CB1-3468-000		1	SCREW,
	CF1-3632-000	D	1	AF LED ASS'Y
	CG1-1389-000	D	1	DIAL ASS'Y
	CG1-1395-000	D	1	FPC ASS'Y, RELEASE
	CG1-3596-000	C	1	PCB ASS'Y, FLASH
	CH2-6116-000	D	1	CONNECTOR, OUTSIDE LCD
	CH5-0117-000	C	1	LCD, OUTSIDE
	X99-0423-000		2	SCREW,
	XA4-6200-457		1	SCREW,
	XA4-9170-287		2	SCREW,
	XA4-9170-357		1	SCREW,
	XA4-9170-457		4	SCREW,
	XA4-9170-459		2	SCREW,
	XA4-9170-507		2	SCREW,
	XA4-9200-557		2	SCREW,

CANON

EOS 3000 QD (JPN)

EOS 3000

EOS 3000 QD

EOS 88

EOS 88 QD


REF. C12-8381

C12-8386

C12-8387

C12-8388

C12-8389



PARTS LIST

REF.No.C12-8381
 C12-8386,87
 C12-8388,89

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB1-1180-000	D	1	LEVER, MIRROR UP
	CB1-1181-000		1	SCREW,
	CB1-1189-000	D	1	HINGE, MAIN MIRROR
	CB1-1197-000	D	1	SHIELD, LIGHT
	CB1-3456-000	D	1	HOLDER, INSIDE LCD
	CB1-3461-000	D	1	WING
	CB1-3478-000	D	1	STOPPER, SUB MIRROR
	CG1-1321-000	D	1	AUTO FOCUS UNIT
	CG1-1376-000	C	1	SHUTTER UNIT (NON-P)
	CG1-3676-000	C	1	SHUTTER UNIT (NON-P)
	CS2-6367-000	D	1	SPRING, SUB MIRROR RETURN
	CS2-6970-000	D	1	SPRING, MIRROR UP
	CS2-6971-000	D	1	SPRING, MIRROR RETURNING
	CY1-1855-000	D	1	MIRROR UNIT
	CY3-1131-000	C	1	FPC ASS'Y, MAIN
	XA4-9170-309		3	SCREW,
	XA4-9170-409		2	SCREW,
	XA4-9170-457		1	SCREW,
	XA4-9170-459		2	SCREW,

CANON

EOS 3000 QD (JPN)

EOS 3000

EOS 3000 QD

EOS 88

EOS 88 QD


REF. C12-8381

C12-8386

C12-8387

C12-8388

C12-8389



PARTS LIST

REF.No.C12-8381
 C12-8386,87
 C12-8388,89

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB1-1133-000	D	1	HOLDER, FOCUSING SCREEN
	CB1-1142-000		5	SCREW,
	CB1-3441-000	C	1	MOUNT, BODY
	CB1-3442-000	D	1	SPRING, MOUNT
	CB1-3443-000(xxx)	D	1	SPACER, MOUNT
	CB1-3451-000	D	1	MASK, FINDER
	CB1-3479-000	D	1	SHIELD, EYEPIECE LIGHT
	CB1-3480-000	D	1	CUSHION, MIRROR
	CB1-3794-000(xxx)	D	1	SPACER, FOCUSING SCREEN
	CB1-3799-000	D	1	MASK, ,EYEPIECE
	CF1-1948-000	D	1	LEVER, LENS LOCK
	CG1-1381-000	D	1	MOUNT CONTACT UNIT
	CS2-5020-000	D	1	SPRING, COIL
	CY1-1610-000	D	1	MIRROR BOX UNIT
	CY1-1852-000	D	1	PLATE, PROTECTION
	XA4-9170-459		2	SCREW,
	XA4-9170-559		2	SCREW,
	YN2-9162-000	D	1	SCREEN, FOCUSING (NON-P)
	YN2-9165-000	D	1	EYEPIECE, FRONT
	YP2-9164-000	C	1	PENTAMIRROR ASS'Y

CANON

EOS 3000 QD (JPN)

EOS 3000

EOS 3000 QD

EOS 88

EOS 88 QD


REF. C12-8381

C12-8386

C12-8387

C12-8388

C12-8389



PARTS LIST



REF.No.C12-8381
 C12-8386,87
 C12-8388,89

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CA1-4257-000	D	1	SEAL, FILM
	CB1-1163-000	D	1	JAW, FILM CARTRIDGE
	CB1-1165-000	D	1	GUIDE, FILM CARTRIDGE
	CB1-1225-000		1	SCREW,
	CB1-3341-000	D	1	BODY
	CB1-3354-000	D	1	HOLDER, DX CONTACT
	CB1-3355-000	D	6	CONTACT, DX
	CB1-3356-000	D	1	COVER, DX CONTACT
	CB1-3357-000	D	1	CONTACT, FILM CARTRIDGE
	CB1-3358-000	D	1	UP LEVER, FILM CARTRIDGE
	CB1-3404-000	D	1	BASE, SPOOL
	CB1-3419-000	D	1	SPOOL
	CB1-3420-000		2	SCREW,
	CB1-3475-000	D	2	CONTACT, BATTERY
	CB1-3792-000		1	SCREW,
	CB1-3797-000	D	1	CUSHION, BATTERY
	CF1-2891-000	C	1	EYEPIECE ASS'Y
	CG1-1383-000	D	1	BOTTOM PLATE ASS'Y
	CS2-5654-000	D	1	SPRING, COIL
	CY1-1851-000	D	1	SIGNAL ASS'Y
	X99-0569-000		1	SCREW,
	XA4-3170-307		2	SCREW,
	XA4-6200-809		2	SCREW,
	XA4-9170-357		2	SCREW,
	XA4-9170-457		2	SCREW,
	XA4-9170-507		4	SCREW,

CANON

EOS 3000 QD (JPN)
EOS 3000
EOS 3000 QD
EOS 88
EOS 88 QD

REF. C12-8381
C12-8386
C12-8387
C12-8388
C12-8389



PARTS LIST

REF.No.C12-8381
C12-8386,87
C12-8388,89

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CA1-3781-000	D	2	SPACER
	CA1-7852-000	D	2	STOPPER, RUBBER
	CB1-2032-000	D	1	PLATE, SEPARATOR
	CB1-2044-000	D	1	STOPPER, SHUTTER CURTAIN
	CF1-2794-000	C	1	CURTAIN, 2ND SHUTTER
	CF1-2795-000	C	1	CURTAIN, 1ST SHUTTER
	XA4-4140-457		2	SCREW

CANON

EOS 3000 QD (JPN)

EOS 3000

EOS 3000 QD

EOS 88

EOS 88 QD


REF. C12-8381

C12-8386

C12-8387

C12-8388

C12-8389



PARTS LIST

REF.No.C12-8381
C12-8386,87
C12-8388,89

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB1-3414-000	D	1	LEVER, CHARGE
	CB1-3416-000	D	1	LEVER, RESET-1
	CB1-3417-000	D	1	LEVER, RESET-2
	CB1-3418-000	D	1	LEVER, BACK COVER
	CB1-3428-000	D	1	COVER, TRIPOD
	CB1-3783-000	D	1	CUSHION, MOTOR
	CB1-3784-000	D	2	WASHER, RUBBER
	CB1-3785-000		2	SCREW,
	CF1-2876-000	D	1	GEAR COVER ASS'Y
	CF1-2878-000	D	1	PLANETARY GEAR ASS'Y 1
	CF1-2879-000	D	1	PLANETARY GEAR ASS'Y 2
	CF1-2880-000	D	1	LOWER COVER ASS'Y
	CS2-0965-000	D	1	GEAR, CHARGE SUN
	CS2-0966-000	D	1	GEAR, PREWIND SUN
	CS2-0969-000	D	1	GEAR, CHARGE TRANSFER
	CS2-0970-000	D	1	GEAR, PREWIND TRANSFER
	CS2-0971-000	D	1	GEAR, REWIND TRANSFER
	CS2-0972-000	D	1	GEAR, SPOOL TRANSFER
	CS2-5651-000	D	1	SPRING, REWIND FRICTION
	CS2-6364-000	D	1	SPRING, RESET
	CS2-6365-000	D	1	SPRING, BACK COVER RESET
	CY1-1853-000	D	1	CAM GEAR ASS'Y
	CY1-1854-000	D	1	PHASE SIGNAL ASS'Y
	CY1-1856-000	D	1	MOTOR ASS'Y
	XA4-9170-357		3	SCREW,
	XA4-9170-409		3	SCREW,
	XA4-9170-507		1	SCREW,

CANON

EOS 3000 QD (JPN)


EOS 3000 QD

EOS 88 QD

REF. C12-8381

C12-8387


C12-8389



PARTS LIST

REF.No.C12-8381
C12-8386,87
C12-8388,89

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CA1-8798-000	D	1	LIGHT SHIELD, DATE WINDOW
	CA1-9602-000	D	2	PIN, DATE CONTACT
	CB1-0183-000	D	1	ROLLER, BACK COVER GUIDE
	CB1-1285-000	D	1	CONTACT, DATE SIGNAL
	CB1-1589-000	D	1	PLATE, SHIELD (QD)
	CB1-3359-000	D	1	HOLDER, ROLLER
	CB1-3360-000	D	1	COVER, BACK (QD)
	CB1-3361-000	D	1	COVER, INNER (QD)
	CB1-3363-000	D	1	COVER, BATTERY (QD)
	CB1-3364-000	D	1	CONTACT, DATE BATTERY (-)
	CB1-3365-000	D	1	CONTACT, DATE BATTERY (+)
	CB1-3786-000	D	1	SHIELD, LIGHT
	CB1-3787-000	D	1	SPRING, CARTRIDGE
	CB1-3793-000		2	SCREW
	CB1-8341-000	D	1	WINDOW, FILM
	CH2-5111-000	D	1	SWITCH, DATE
	CH4-0532-000	D	1	PCB ASS'Y, DATE (QD)
	CS2-3233-000	D	1	SHAFT, ROLLER HOLDER
	CS2-6966-000	E	1	SPRING, TORSION
	X99-0470-000		1	NUT
	X99-0685-000		5	SCREW,
	XA1-7170-407		1	SCREW,
	XA4-3170-459		1	SCREW
	XA4-9170-257		3	SCREW,



PARTS LIST

REF.No.C12-8381
C12-8386,87
C12-8388,89

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB1-0183-000	D	1	ROLLER, BACK COVER GUIDE
	CB1-3359-000	D	1	HOLDER, ROLLER
	CB1-3366-090	D	1	WINDOW, FILM
	CB1-3786-000	D	1	SHIELD, LIGHT
	CB1-3787-000	D	1	SPRING, CARTRIDGE
	CB1-3793-000		2	SCREW,
	CS2-3233-000	D	1	SHAFT, ROLLER HOLDER
	CS2-6966-000	D	1	SPRING, TORSION
	CY3-1080-000	D	1	COVER, BACK (NON-QD)

ELECTRIC PARTS LIST

REF.No.C12-8381

C12-8386,87

C12-8388,89

NEW	SYMBOL	PARTS NO.	DESCRIPTION
	EF IC	CH4-0641-000	EF IC, LC4090
	AE IC	CH4-0642-000	AE IC, LC4089
	DC/DC IC	WA4-5457-000	DC/DC IC, MB3776APNF
	MOTIR DR	WA4-6332-000	MOTOR DRIVER, MPC17A10SVM
		Y11-3402-000	LEAD
		Y11-3403-000	LEAD
		Y11-3702-000	LEAD
		Y11-3703-000	LEAD
		Y11-3901-000	LEAD
		Y11-3902-000	LEAD
		Y11-3904-000	LEAD
		Y11-3906-000	LEAD
		Y11-3907-000	LEAD
		Y11-3909-000	LEAD
		Y11-3911-000	LEAD
		Y11-3914-000	LEAD
		Y11-5001-000	LEAD
		Y11-5011-000	LEAD