




EOS 100 QD	REF. No.C12-8151
EOS 100 PANORAMA	C12-8152
EOS ELAN QD	C12-8153
EOS ELAN	C12-8154
EOS 100	C12-8156

PARTS CATALOG

	省略記号 / Code	原産地表示 / Country of Origin
1.	CMJ	CANON INC. MADE IN JAPAN
2.		

CANON EOS 100 QD
EOS 100 PANORAMA
EOS ELAN
EOS 100

REF.No. C12-8151
C12-8152
C12-8154
C12-8156




PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6

NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CB1-0273-000		5	SCREW, CROSS-RECESS,PH
	CB1-0276-000		7	SCREW, CROSS-RECESS,PH
	CB1-0282-000		1	SCREW, CROSS-RECESS,PH
	CB1-1770-000	C	1	COVER, LATCH
	CB1-1784-000	D	1	GRIP
	CB1-1801-000	E	1	CAP, BLIND
	CB1-1802-000		1	SCREW, CROSS-RECESS,PH
	CB1-1954-000	E	2	BUTTON
	CB1-1957-000	E	1	BUTTON, AE LOCK
	CB1-1958-000	E	1	BUTTON, DRIVE MODE
	CB1-1959-000	E	1	BUTTON, AF MODE
	CF1-2627-000	C	1	BATTERY COVER ASS'Y
	CG1-1193-000	D	1	PANEL ASS'Y, FRONT
	CG1-1194-000	D	1	PANEL ASS'Y, FRONT
	CG1-1203-000	E	1	PANEL ASS'Y, FRONT
	CG1-1208-000	D	1	PANEL ASS'Y, FRONT
	CG1-1498-000	D	1	PANEL ASS'Y, FRONT
	CH2-5117-000	D	2	CONTACT, RUBBER
	CH2-5119-000	E	1	CONTACT, RUBBER
	CH2-5120-000	E	1	CONTACT, RUBBER
	CS2-5596-000	E	1	SPRING, BACK COVER LATCH
	CY1-1487-000	D	1	LEVER, LATCH
	CY1-1566-000	D	1	TOP COVER ASS'Y
	CY1-1683-000	E	1	COVER, BASE
	CY1-1684-000	E	1	BASE COVER ASS'Y, PANO.
	X99-0699-000		1	SCREW, CROSS-RECESS,PH
	XA4-9170-459		2	SCREW, CROSS-RECESS,PH

CANON EOS 100 QD
EOS 100 PANORAMA
EOS ELAN
EOS 100

REF.No. C12-8151
 C12-8152
 C12-8154
 C12-8156



PARTS LIST



REF. NO. C12-8151, 2, 3, 4, 6

NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CA1-8625-000	E	1	PIN, FLASH INHIBIT
	CB1-1981-000	E	1	COVER, FLASH
	CB1-1983-000	E	1	PANEL, FLASH
	CB1-1998-000		1	SCREW, CROSS-RECESS, PH
	CB1-2000-000		1	SCREW, CROSS-RECESS, PH
	CB1-2008-000	E	1	SCREW, CROSS-RECESS, PH
	CB1-2009-000	E	1	SCREW, CROSS-RECESS, PH
	CB1-2011-000	E	1	CLASP
	CB1-2016-000		1	CUSHION
	CB1-2017-000		1	CUSHION
	CF1-2712-000	E	1	GEAR ASS'Y, COUPLING
	CH1-1232-000	E	1	FLEX, FLASH
	CH1-1238-000	E	1	FLEX, TOP
	CH9-0223-000	E	1	SWITCH, POP-UP
	CS2-0776-000	E	1	GEAR, 2ND FLASH
	CS2-0777-000	E	2	GEAR, IDLE
	CS2-6315-000	E	1	SPRING, POP UP
	CS2-6316-000	E	1	SPRING, ZOOM
	CY1-1574-000	D	1	GEAR ASS'Y, FLASH CAM
	CY1-1576-000	E	1	FLASH GEAR ASS'Y
	XA1-7170-207		1	SCREW, CROSS-RECESS, PH
	XA4-3170-409		1	SCREW, CROSS-RECESS, FCH
	XA4-9170-307		2	SCREW, CROSS-RECESS, PH
	XA4-9170-357		2	SCREW, CROSS-RECESS, PH
	XA4-9170-407		2	SCREW, CROSS-RECESS, PH
	XA4-9170-609		2	SCREW, CROSS-RECESS, PH

CANON EOS 100 QD
EOS 100 PANORAMA
EOS ELAN
EOS 100

REF.No. C12-8151
 C12-8152
 C12-8154
 C12-8156

CY1-1575 ACF-882




PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6

NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CA1-6504-040	D	1	SHOE, ACCESSORY
	CA1-8666-050	E	1	BASE, ACC. SHOE
	CA1-9328-000	C	1	SPRING, PLATE
	CB1-0132-000	D	1	BUTTON, RELEASE
	CB1-0284-000	F	1	SCREW, CROSS-RECESS, PH
	CB1-1803-000	D	1	SHIELD, DUST
	CB1-1952-000	C	1	DIAL, MODE
	CB1-1956-000	E	1	WINDOW, LCD
	CB1-1960-000	E	1	BUTTON, LOCK
	CB1-1992-000(XXX)	E	1	FLASH DOWN LATCH
	CG1-1196-000	E	1	FLASH TUBE ASS'Y
	CH6-1029-000	E	1	COIL, TRIGGER
	CS2-5409-000	C	1	SPRING, COIL
	CS2-5410-000	E	1	SPRING, BUTTON LOCK
	CY1-1483-000	E	1	RED-EYE LAMP ASS'Y
	CY1-1484-000	D	1	COVER, TOP
	CY1-1575-000	E	1	FLASH TUBE ASS'Y
	XA1-3170-507		4	SCREW, CROSS-RECESS, FCH
	XA1-7170-207		2	SCREW, CROSS-RECESS, PH
	XA1-7170-227		1	SCREW, CROSS-RECESS, PH
	XA1-7170-257		1	SCREW, CROSS-RECESS, PH
	XA4-9170-407		1	SCREW, CROSS-RECESS, PH
	XD2-1100-102		1	E RING
	XD2-1100-132		1	WASHER, RETAINING
	XG8-1100-581		1	BALL, STEEL

CANON EOS 100 QD
EOS 100 PANORAMA
EOS ELAN
EOS 100

REF.No. C12-8151
 C12-8152
 C12-8154
 C12-8156




PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6

NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CB1-1769-000	D	1	COVER, BCD
	CB1-1772-000	E	1	LUG, NECK STRAP
	CB1-1776-000	E	1	PLATE, BCD
	CB1-1777-000	E	1	BUTTON, BCD
	CB1-1785-000	E	1	BUTTON, REWIND
	CB1-1791-000	E	1	CASE, LCD
	CB1-1792-000	E	1	BASE, LCD
	CB1-1793-000	D	1	SPRING, LCD HOLDER
	CG1-1190-000	D	1	DIAL ASS'Y
	CH2-5118-000	D	1	CONTACT, RUBBER
	CH2-6108-000	D	1	CONNECTOR, LCD
	CH3-0107-000	E	1	DC/DC ASS'Y
	CH5-0108-000	D	1	LCD
	CS2-5574-000	D	1	SPRING, BACK FLEX
	XA1-7170-407		1	SCREW, CROSS-RECESS, PH
	XA4-9170-407		2	SCREW, CROSS-RECESS, PH
	XA4-9170-457		3	SCREW, CROSS-RECESS, PH
	XA4-9170-509		2	SCREW, CROSS-RECESS, PH
	XA4-9200-509		2	SCREW, CROSS-RECESS, PH
	XA4-9200-607		2	SCREW, CROSS-RECESS, PH
	XA4-9200-857		2	SCREW, CROSS-RECESS, PH

CANON EOS 100 QD
EOS 100 PANORAMA
EOS ELAN
EOS 100


REF.No. C12-8151
C12-8152
C12-8154
C12-8156



P A R T S L I S T

REF. NO. C12-8151, 2, 3, 4, 6

NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CA1-7780-000	E	1	INTERLOCK, LENS MOTOR
	CB1-1206-000	E	1	HOLDER, ILC
	CB1-1875-000	E	1	SHIELD, LIGHT
	CB1-1892-000	E	1	CASE, REMOTE
	CF1-2714-000	E	1	CONTACT, INTERLOCK
	CG1-1202-000	D	1	DISPLAY FLEX ASS'Y
	CH9-0225-000	D	1	SIDE CBA
	CH9-0226-000	D	1	BOTTOM CBA
	CY1-1498-000	E	1	WING PLATE ASS'Y
	XA4-7170-457		1	SCREW, CROSS-RECESS, PH
	XA4-9170-307		2	SCREW, CROSS-RECESS, PH
	XA4-9170-357		2	SCREW, CROSS-RECESS, PH
	XA4-9170-359		1	SCREW, CROSS-RECESS, PH
	XA4-9170-457		2	SCREW, CROSS-RECESS, PH




PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6

NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CA1-5079-000(XXX)	D	1	SPACER
	CA1-7752-000	E	2	WASHER, WAVE
	CA1-7777-000	C	1	MOUNT, BODY
	CB1-0274-000		4	SCREW, CROSS-RECESS, PH
	CB1-1133-000	E	1	HOLDER, FOCUSING PLATE
	CB1-1170-000		2	SCREW, CROSS-RECESS, PH
	CB1-1876-000	E	1	BRACKET, AF
	CB1-1884-000	D	1	CUSHION MIRROR
	CB1-1893-000(XXX)	E	1	WASHER, FINDER BACK ADJUST
	CB1-1894-000	E	1	MASK, FINDER
	CB1-1896-000	D	1	PLATE, PROTECTION
	CB1-1897-000	D	1	PLATE, GND
	CB1-1902-000		2	SCREW, CROSS-RECESS, PH
	CB1-2659-000(XXX)	E	1	SPACER, MOUNT
	CB1-4085-000		4	SCREW, CROSS-RECESS, PH
	CF1-1948-000	E	1	LEVER, LENS LOCK
	CG1-1182-000	D	1	MOUNT CONTACT ASS'Y
	CG1-1183-000	E	1	AF ASS'Y
	CG1-1201-070	D	1	MAIN FLEX ASS'Y
	CN1-0202-000	E	1	PENTAPRISM
	CN1-5301-000	E	1	LENS, PARTIAL METERING
	CS2-5020-000	E	1	SPRING, COIL
	CS2-7205-000	D	1	SPRING, MOUNT
	CY1-1280-000	C	1	MOUNT, BODY
	CY1-1488-000	D	1	FLASH AUTO SENSER ASS'Y
	X99-0689-000		2	SCREW, CROSS-RECESS, PH
	XA4-1170-407		1	SCREW, CROSS-RECESS, PH
	XA4-9170-459		2	SCREW, CROSS-RECESS, PH
	XA4-9170-509		2	SCREW, CROSS-RECESS, PH
	XD1-1102-120		1	WASHER
	XD1-1102-121		1	WASHER
	YN2-0276-000		1	SCREEN, FOCUSING
	YN2-0277-000		1	PRISM, ILC INFORMATION
	YN2-0280-000		1	SCREEN, PANORAMA FOCUSING

CANON EOS 100 QD
EOS 100 PANORAMA
EOS ELAN
EOS 100

REF.No. C12-8151
 C12-8152
 C12-8154
 C12-8156



CAI-7809-000 detail

A	SIZE
2.00 mm (200)	
2.20 mm (220)	
2.40 mm (240)	
2.60 mm (260)	
2.80 mm (280)	
3.00 mm (300)	
3.20 mm (320)	
3.40 mm (340)	


PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6

NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CA1-7809-000(XXX)	E	1	COLLAR, SHUTTER CHARGE LEVER
	CA1-8743-000		1	COLLAR, SHUTTER
	CB1-0218-000	E	1	STOPPER, SUB MIRROR
	CB1-1866-000	E	1	BAND, MOTOR
	CB1-1867-000	E	3	CUSHION, MOTOR
	CB1-1878-000	E	1	LEVER, RETURN
	CB1-1882-000	E	1	HINGE-L, MAIN MIRROR
	CB1-1883-000	E	1	HINGE-R, MAIN MIRROR
	CF1-2692-000	D	1	MOTOR, M2
	CF1-2698-000	D	1	LEVER, SHUTTER CHARGE
	CH1-1229-000	E	1	BOARD, PHASE CIRCUIT
	CS2-0760-000	E	1	GEAR 1, MIRROR
	CS2-0761-000	E	1	GEAR 2, MIRROR
	CS2-0763-000	E	1	GEAR 4, MIRROR
	CS2-0765-000	E	1	GEAR 6, MIRROR
	CS2-0767-000	E	1	GEAR 8, MIRROR
	CS2-0768-000	E	1	GEAR, MIRROR UP
	CS2-6310-000	E	1	SPRING, MIRROR UP
	CS2-6312-000	E	1	SPRING, SUBMIRROR RETURN
	CY1-1489-000	E	1	PLATE ASS'Y, GEAR BASE
	CY1-1490-000	D	1	MIRROR ASS'Y
	CY1-1491-000	E	1	GEAR ASS'Y, 2ND PLANETARY
	CY1-1492-000	E	1	GEAR ASS'Y, 1ST PLANETARY
	CY1-1493-000	E	1	LEVER, MIRROR UP
	CY1-1494-000	E	1	GEAR ASS'Y, CHARGE CAM
	CY1-1592-000	D	1	MIRROR BOX ASS'Y
	XA4-1170-407	D	1	SCREW, CROSS-RECESS, PH
	XA4-9170-359		2	SCREW, CROSS-RECESS, PH
	XA4-9170-407		2	SCREW, CROSS-RECESS, PH
	XA4-9170-707		1	SCREW, CROSS-RECESS, PH
	XD2-1100-102		1	E RING

CANON EOS 100 QD
EOS 100 PANORAMA
EOS ELAN
EOS 100

REF.No. C12-8151
C12-8152
C12-8154
C12-8156



(ACF-895, 009)
CG1-1179
CG1-1491 (PANO)

XA4-4140-457_{x2}

N.S

(ACF-948, 009)
CB1-2044

N.S

CF1-2764

N.S

CB1-2032

CF1-2763

CA1-7852_{x2}

N.S


PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6

NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CA1-7852-000	E	2	STOPPER
	CB1-2032-000	E	1	PLATE, SEPARATOR
	CB1-2044-000	E	1	RUBBER, STOPPER
	CF1-2763-000	C	1	CURTAIN, SHUTTER (2ND)
	CF1-2764-000	C	1	CURTAIN, SHUTTER (1ST)
	CG1-1179-000	C	1	SHUTTER UNIT
	CG1-1491-000	C	1	PANORAMA SHUTTER UNIT
	XA4-4140-457		2	SCREW, CROSS-RECESS, PH

CANON EOS 100 QD
EOS 100 PANORAMA
EOS ELAN
EOS 100

REF.No. C12-8151
 C12-8152
 C12-8154
 C12-8156




PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6

NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CB1-1160-000	E	1	CONTACT, DX
	CB1-1162-000	E	1	CONTACT, FILM CARTRIDGE
	CB1-1771-000	E	1	LUG, NECK STRAP
	CB1-1774-000	E	1	BASE, MODE DIAL
	CB1-1780-000	E	1	CONTACT+, BATTERY
	CB1-1781-000	E	1	CONTACT-, BATTERY
	CB1-1782-000	E	1	CONTACT, RESET
	CB1-1783-000	E	1	SPACER, CONTACT
	CB1-1826-000	E	1	COVER, DX
	CF1-2628-000	D	1	EYEPiece
	CF1-2709-000	E	1	BEEPER
	CG1-1495-000	D	1	PANORAMA EYEPiece UNIT
	CH1-1236-000	E	1	DX FLEX
	CY1-1500-000	E	1	CONTACT, MODE
	X71-9749-000		1	RETAINER
	XA4-1200-809		2	SCREW, CROSS-RECESS, PH
	XA4-9170-357		1	SCREW, CROSS-RECESS, PH
	XA4-9170-407		2	SCREW, CROSS-RECESS, PH
	XA4-9170-457		6	SCREW, CROSS-RECESS, PH
	XA4-9200-509		2	SCREW, CROSS-RECESS, PH

CANON EOS 100 QD
EOS 100 PANORAMA
EOS ELAN
EOS 100

REF.No. C12-8151
 C12-8152
 C12-8154
 C12-8156




PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6

NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CA1-4257-000	D	1	SEAL, FILM
	CB1-1163-000	E	1	JAW, FILM CARTRIDGE
	CB1-1165-000	D	1	GUIDE, FILM CARTRIDGE
	CB1-1265-000		1	SCREW, CROSS-RECESS, PH
	CB1-1773-000	E	1	HINGE, LOWER BACK COVER
	CB1-1800-000	E	1	BASE, SPOOL
	CB1-1820-000		3	SCREW, CROSS-RECESS, PH
	CB1-1821-000	D	1	BASE, WIND
	CB1-1822-000	D	1	SPOOL
	CB1-1828-000	E	1	CUSHIN
	CB1-1832-000	D	1	SOCKET, TRIPOD
	CB1-4065-090	E	1	BODY, PANORAMA
	CY1-1495-000	E	1	SIGNAL UNIT
	CY1-1611-000	D	1	PANORAMA FLEX
	XA4-1170-257		1	SCREW, CROSS-RECESS, PH
	XA4-1170-359		1	SCREW, CROSS-RECESS, PH
	XA4-9170-407		2	SCREW, CROSS-RECESS, PH
	XA4-9170-409		1	SCREW, CROSS-RECESS, PH
	XA4-9170-457		4	SCREW, CROSS-RECESS, PH
	XA4-9170-459		1	SCREW, CROSS-RECESS, PH
	XA4-9200-607		2	SCREW, CROSS-RECESS, PH

CANON EOS 100 QD
EOS 100 PANORAMA
EOS ELAN
EOS 100


REF.No. C12-8151
 C12-8152
 C12-8154
 C12-8156



PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6


NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CB1-1812-000	E	1	HOUSING, GEAR
	CB1-1813-000	E	1	HOUSING, FORK
	CB1-1814-000	D	1	BELT, GEAR DRIVE
	CB1-1815-000	E	1	BELT, GEAR DRIVE
	CB1-1817-000	E	1	PULLEY, IDLER
	CB1-1819-000	E	3	MOUNT, VIBRATION
	CB1-1830-000	E	1	GUIDE, BELT
	CB1-1831-000	E	1	GUIDE, BELT
	CF1-2691-000	D	1	MOTOR, M1
	CF1-2702-000	E	1	FORK ASS'Y
	CS2-0749-000	E	1	GEAR, WIND 2ND
	CS2-0750-000	E	1	GEAR, WIND SUN
	CS2-0752-000	E	1	GEAR, SPOOL DRIVE
	CS2-0753-000	D	1	GEAR, SPOOL
	CS2-0754-000	E	1	GEAR, REWIND DRIVE
	CS2-0755-000	E	1	GEAR, REWIND
	CY1-1496-000	E	1	WIND, PLANETARY GEAR ASS'Y
	CY1-1499-000	D	1	GEAR, WIND 1ST
	CY1-1682-000	E	1	BASEPLATE, TRANSPORT
	XA4-9170-407		4	SCREW, CROSS-RECESS, PH
	XA4-9170-507		2	SCREW, CROSS-RECESS, PH



PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6


NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CA1-6525-000	E	1	PLATE, SPRING
	CA1-8646-000	E	1	WINDOW, FILM
	CA1-8648-000	D	1	SHIELD, LIGHT
	CA1-8798-000	E	1	LIGHT SHIELD, DATE WINDOW
	CA1-8799-000	E	1	SHIELD, DATE
	CB1-0183-000	D	1	ROLLER-1, BACK COVER GUIDE
	CB1-0193-040	E	1	SPRING, CARTRIDGE
	CB1-1922-000	E	1	COVER, DATE INNER
	CB1-1923-000	D	1	DIAL, REAR INPUT
	CB1-1924-000	E	1	CONTACT, DIAL
	CB1-1925-000	D	1	CAM, REAR INPUT DIAL
	CB1-1926-000	E	1	DETENT, DIAL
	CB1-1927-000	E	1	CONTACT, DIAL LOCK SWITCH
	CB1-1928-000	E	1	HOLDER, ROLLER
	CB1-1929-000	E	1	CONTACT DATE BATTERY (+)
	CB1-1930-000	E	1	CONTACT DATE BATTERY (-)
	CB1-1931-000	E	1	CONTACT BASE, TRIGGER
	CB1-1932-000	D	1	COVER, DATE BATTERY
	CB1-1933-000		1	SCREW, CROSS-RECESS, PH
	CB1-1934-000		1	SCREW, CROSS-RECESS, PH
	CB1-2748-000		2	SCREW, CROSS-RECESS, PH
	CF1-2715-000	D	1	PLATE, PRESSURE
	CG1-1191-000	E	1	COVER ASS'Y, QD BACK
	CH1-1237-000	D	1	FLEX, BACK
	CH1-1280-000	E	1	BOARD, CONTACT
	CH2-5111-000	E	1	SWITCH, DATE
	CH4-0338-000	E	1	DATE CBA
	CH4-0515-000	E	1	BCD SENSOR
	CS2-3233-000	E	1	SHAFT, ROLLER HOLDER
	CS2-5594-000	E	1	SPRING, COIL
	CS2-6966-000	E	1	SPRING, ROLLER
	CY1-1581-000	E	1	COVER UNIT, QD
	VR5-3560-473	E	1	RESISTOR 47 K OHM
	X99-0427-000		3	SCREW, CROSS-RECESS, PH
	X99-0470-000		1	NUT
	X99-0582-000		1	SCREW, CROSS-RECESS, PH
	X99-0583-000		1	SCREW, CROSS-RECESS, PH
	X99-0685-000		5	SCREW, CROSS-RECESS, PH
	XA1-7170-407		2	SCREW, CROSS-RECESS, PH
	XA4-3170-457		1	SCREW, CROSS-RECESS, PH
	XD1-1103-614		1	WASHER
	XG8-1100-581		1	BALL



PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6

NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CA1-6525-000	E	1	PLATE, SPRING
	CA1-8646-000	E	1	WINDOW, FILM
	CA1-8648-000	D	1	SHIELD, LIGHT
	CB1-0183-000	D	1	ROLLER-1, BACK COVER GUIDE
	CB1-0193-000	E	1	SPRING, CARTRIDGE
	CB1-1923-000	D	1	DIAL, REAR INPUT
	CB1-1924-000	E	1	CONTACT, DIAL
	CB1-1925-000	D	1	CAM, REAR INPUT DIAL
	CB1-1926-000	E	1	DETENT, DIAL
	CB1-1927-000	E	1	CONTACT, DIAL LOCK SWITCH
	CB1-1928-000	E	1	HOLDER, ROLLER
	CB1-1933-000		6	SCREW, CROSS-RECESS, PH
	CB1-1934-000		1	SCREW, CROSS-RECESS, PH
	CB1-1941-000	E	1	COVER, INNER
	CB1-2748-000		2	SCREW, CROSS-RECESS, PH
	CF1-2715-000	D	1	PLATE, PRESSURE
	CG1-1192-000	E	1	COVER ASS'Y, BACK
	CH1-1237-000	D	1	FLEX, BACK
	CH1-1280-000	E	1	BOARD, CONTACT
	CH4-0515-000	E	1	BCD SENSOR
	CS2-3233-000	E	1	SHAFT, ROLLER HOLDER
	CS2-5594-000	E	1	SPRING, COIL
	CS2-6966-000	E	1	SPRING, ROLLER
	X99-0582-000		1	SCREW, CROSS-RECESS, PH
	X99-0583-000		1	SCREW, CROSS-RECESS, PH
	XD1-1103-614		1	WASHER
	XG8-1100-581		1	BALL




PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6


NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CA1-6525-000	E	1	PLATE, SPRING
	CA1-8646-000	E	1	WINDOW, FILM
	CA1-8648-000	D	1	SHIELD, LIGHT
	CA1-8798-000	E	1	LIGHT SHIELD, DATE WINDOW
	CB1-0183-000	D	1	ROLLER-1, BACK COVER GUIDE
	CB1-1923-000	D	1	DIAL, REAR INPUT
	CB1-1924-000	E	1	CONTACT, DIAL
	CB1-1925-000	D	1	CAM, REAR INPUT DIAL
	CB1-1926-000	E	1	DETENT, DIAL
	CB1-1927-000	E	1	CONTACT, DIAL LOCK SWITCH
	CB1-1928-000	E	1	HOLDER, ROLLER
	CB1-1930-000	E	1	CONTACT DATE BATTERY (-)
	CB1-1932-000	D	1	COVER, DATE BATTERY
	CB1-1933-000		1	SCREW, CROSS-RECESS, PH
	CB1-1934-000		1	SCREW, CROSS-RECESS, PH
	CB1-3845-000	E	1	SPRING, CARTRIDGE
	CB1-4067-000	E	1	COVER, PN DATE INNER
	CB1-4070-000	E	1	CONTACT DATE BATTERY (+)
	CB1-4071-000	E	1	SHIELD, DATE
	CB1-4074-000	E	1	LUG, GND
	CF1-2719-000	D	1	PLATE, PRESSURE
	CF1-2931-000	D	1	PLATE, PANORAMA PRESSURE
	CG1-1496-000	E	1	COVER ASS'Y, QD-P BACK
	CH1-1280-000	E	1	BOARD, CONTACT
	CH1-1341-000	D	1	FLEX, PN BACK
	CH2-5111-000	E	1	SWITCH, DATE
	CH4-0515-000	E	1	BCD SENSOR
	CH4-0657-000	E	1	PN DATE CBA
	CS2-3233-000	E	1	SHAFT, ROLLER HOLDER
	CS2-5594-000	E	1	SPRING, COIL
	CS2-6966-000	E	1	SPRING, ROLLER
	X99-0427-000		2	SCREW, CROSS-RECESS, PH
	X99-0470-000		1	NUT
	X99-0582-000		1	SCREW, CROSS-RECESS, PH
	X99-0583-000		1	SCREW, CROSS-RECESS, PH
	X99-0685-000		5	SCREW, CROSS-RECESS, PH
	XA1-7170-407		2	SCREW, CROSS-RECESS, PH
	XA4-3170-457		1	SCREW, CROSS-RECESS, PH
	XD1-1103-614		1	WASHER
	XG8-1100-581		1	BALL

CANON EOS 100 Q.D., ELAN, 100 (ACC)


C46-1692 SEMI HARD CASE EH6-L
 C46-1693 SEMI HARD CASE EH6-LL



C56-1511 WIDE STRAP EW-100



C51-9991 GRIP EXTENSION GR-70



PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6 (ACC.)

NEW	PART NO.	CLASS	QTY	DESCRIPTION
	CA4-0390-000	D	2	LOOP
	CA4-4411-000	D	1	SCREW, TIGHTENING
	CA4-4411-000	D	1	SCREW, TIGHTENING
	CA4-4851-000	E	2	CLASP
	CA4-4851-000	E	1	CLASP
	CA4-4957-000	D	1	PAD, GRIP
	CB4-0072-000		7	SCREW, CROSS-RECESS, PH
	CB4-0076-000	E	1	BODY, GRIP
	CB4-0077-000	E	1	PLATE, GRIP(GR-70)
	CB4-0078-000	E	1	STRAP, WRIST
	CY3-0005-000	D	1	HOOK
	CY3-0025-000	D	1	HOOK
	XD2-1100-502		1	RENTAINING RING(E-TYPE)
	XD2-1200-502	F	1	RENTAINING RING(E-TYPE), M5

ELECTRIC PARTS LIST

REF. NO. C12-8151, 2, 3, 4, 6

NEW	SYMBOL	PARTS NO.	CLASS	QTY	DESCRIPTION	REMARKS
	IC1	CH4-0211-000	D	1	AE SENSOR	LC4021
	IC2	CH4-0588-000	D	1	I/O	TB1113F
	IC3	CH4-0587-000	D	1	LCD DRIVER	SN103932
	IC4	ACF-836 (NON STOCK)				
	IC5	CH4-0218-000	D	1	M DRIVER	MPC1710B
	IC6	CH4-0218-000	D	1	M DRIVER	MPC1710B
	IC9	CH4-0213-000	D	1	T-MOS	SFX10
		CH2-3687-000			LEAD	BLACK
		Y11-3702-000 (ACF-839)			LEAD	BLACK
		Y11-3703-000 (ACF-839)			LEAD	RED
		Y11-3901-000			LEAD	WHITE
		Y11-3902-000			LEAD	BLACK
		Y11-3903-000			LEAD	RED
		Y11-3904-000			LEAD	PINK
		Y11-3907-000			LEAD	YELLOW
		Y11-3909-000			LEAD	GREEN
		Y11-3911-000			LEAD	BLUE
		Y11-3912-000			LEAD	PURPLE
		Y11-3914-000			LEAD	GRAY
		Y11-5001-000			LEAD	WHITE
		Y11-5011-000			LEAD	BLUE
		Y11-5102-000			LEAD	BLACK