



SURE SHOT SLEEK

PRIMA MINI II

SURE SHOT SLEEK DATE

PRIMA MINI II DATE

AUTOBOY F-XL

REF.NO.C13-3572

C13-3573

C13-3582

C13-3583

C13-3591


<W/Service M.>

A separate Service Manual for this product will not be issued. The SURE SHOT ESPRIT Service Manual CY8-1200-112 & The SURE SHOT A-1 Service Manual CY8-1200-117 should be used with the exception of the items separately listed in this Parts Catalog w/Service Manual.

CODE	Country of Origin
C	CANON INC.
CJ	CANON INC. JAPAN
CJMM	CANON INC. JAPAN MADE IN MALAYSIA
CJMC	CANON INC. JAPAN MADE IN CHINA
CMJ	CANON INC. MADE IN JAPAN
CMT	CANON INC. MADE IN TAIWAN
CMC	CANON INC. MADE IN CHINA

CANON [A] SURE SHOT SLEEK
 [B] PRIMA MINI II
 [C] SURE SHOT SLEEK DATE
 [D] PRIMA MINI II DATE
 [E] AUTOBOY F-XL

REF. NO. CI3-3572
 CI3-3573
 CI3-3582
 CI3-3583
 CI3-3591




PARTS LIST

REF.No.C13-3572,73
C13-3582,83
C13-3591

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CA1-6172-000	E	1	BODY, STRAP LOCK
	CA1-6173-000	E	1	HOOK, STRAP LOCK
	CA1-6225-000	E	1	STRAP
	CB1-2346-000		1	SCREW, CROSS-RECESS, PH
	CB1-3569-000		2	SCREW, CROSS-RECESS, PH
	CB1-3584-000	D	1	LEVER, PANORAMA
	CB1-3590-000	D	1	SEAL, PANORAMA
	CB1-3816-000		1	SCREW, CROSS-RECESS, PH
	CB1-6049-000	D	1	COVER, BUTTON
	CB1-6056-000		3	SCREW, CROSS-RECESS, PH
	CB1-6057-000		1	SCREW, CROSS-RECESS, PH
	CF1-2911-000	C	1	REAR COVER ASS'Y
	CH2-5146-000	D	1	BUTTON, REWIND
	CH2-5194-000	D	1	BUTTON, RELEASE
	CY1-1831-000	C	1	COVER, BOTTOM(CMT)
	CY1-1832-000	C	1	COVER, BOTTOM(C)
	CY1-1833-000	C	1	COVER, BOTTOM(P-CMT)
	CY1-1834-000	C	1	COVER, BOTTOM(CMC)
	CY1-1835-000	C	1	COVER, BOTTOM(CJ)
	CY1-1836-000	C	1	COVER, BOTTOM(P-CMC)

CANON [A] SURE SHOT SLEEK
 [B] PRIMA MINI II
 [C] SURE SHOT SLEEK DATE
 [D] PRIMA MINI II DATE
 [E] AUTOBOY F-XL

REF. NO. C13-3572
 C13-3573
 C13-3582
 C13-3583
 C13-3591




PARTS LIST

REF.No.C13-3572,73
C13-3582,83
C13-3591

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB1-4697-000		2	SCREW, CROSS-RECESS, PH
	CB1-4974-000		5	SCREW, CROSS-RECESS, PH
	CB1-6013-000	C	1	GLASS, FLASH
	CB1-6017-000	C	1	BARRIER
	CB1-6018-000	D	1	LEVER, BARRIER
	CB1-6019-000	D	1	PLATE, BARRIER
	CB1-6024-000	D	1	SHIELD, LIGHT
	CB1-6025-000	C	1	DIAL, MODE
	CB1-6029-000	C	1	RUBBER, GRIP
	CB1-6048-000	C	1	TAPE, GRIP
	CF1-3234-000	C	1	KNOB ASS'Y, BARRIER
	CF1-3237-000	C	1	GLASS ASS'Y, FRONT
	CS2-5609-000	D	1	SPRING, BARRIER
	CS2-5610-000	D	1	SPRING, CLICK
	CS2-5611-000	C	1	SPRING, CLICK
	CS2-7192-000	C	1	SWITCH, MODE
	CY1-1825-000	C	1	COVER ASS'Y, FRONT(S.S.SLEEK)
	CY1-1826-000	C	1	COVER ASS'Y, FRONT(PRIMA MINI II)
	CY1-1827-000	C	1	COVER ASS'Y, FRONT(S.S.SLEEK QD)
	CY1-1828-000	C	1	COVER ASS'Y, FRONT(PRIMA MINI II QD)
	CY1-1829-000	C	1	COVER ASS'Y, FRONT(A.B.F-XL)
	XG8-1100-561	C	1	BALL, CLICK
	XG8-1100-581	C	1	BALL, CLICK

CANON [A] SURE SHOT SLEEK
 [B] PRIMA MINI II
 [C] SURE SHOT SLEEK DATE
 [D] PRIMA MINI II DATE
 [E] AUTOBOY F-XL

REF. NO. C13-3572
 C13-3573
 C13-3582
 C13-3583
 C13-3591



PARTS LIST

REF.No.C13-3572,73


C13-3582,83

C13-3591

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB1-1614-000	E	4	CONTACT, ISO
	CB1-3492-000	E	1	HOLDER, REWIND GEAR
	CB1-3504-000	E	1	GEAR, COUNTER
	CB1-3506-000	E	1	LEVER, PRESSURE
	CB1-3515-000	E	1	REFLECTOR, RED EYE
	CB1-3543-000	E	1	HOLDER, CONNECTOR
	CB1-3544-000	E	1	RUBBER, CONNECTOR
	CB1-3545-000	E	1	HOLDER, FLEX
	CB1-3572-000		1	SCREW, CROSS-RECESS, PH
	CB1-6028-000	E	1	COUNTER, FILM
	CF1-2898-000	E	1	GEAR, PLANETARY
	CF1-2900-000	D	1	SWITCH, BACK COVER
	CF1-2902-000	E	1	FORK GEAR ASS'Y
	CG1-1633-000	C	1	MAIN FPC ASS'Y
	CG9-0419-000	D	1	FLASH UNIT
	CG9-0423-000	C	1	FLASH BOARD 2 ASS'Y
	CS2-0983-000	E	1	GEAR1, WIND
	CS2-0984-000	E	1	GEAR2, WIND
	CS2-0985-000	E	1	GEAR, SUN
	CS2-0986-000	E	1	GEAR1, REWIND
	CS2-0987-000	E	3	GEAR2, REWIND
	CS2-5658-000	E	1	SPRING, BACK COVER
	CS2-5659-000	D	1	SPRING, COUNTER LEVER
	CS2-6371-000	E	1	SPRING, PRESSURE
	CS2-6372-000	E	1	SPRING, COUNTER
	X71-9749-000	B	2	RETAINER
	XA4-9170-309		2	SCREW, CROSS-RECESS, PH
	XA4-9170-409		5	SCREW, CROSS-RECESS, PH
	XA4-9170-459		3	SCREW, CROSS-RECESS, PH
	XA4-9170-509		1	SCREW, CROSS-RECESS, PH
	XA4-9170-609		1	SCREW, CROSS-RECESS, PH

CANON [A] SURE SHOT SLEEK
 [B] PRIMA MINI II
 [C] SURE SHOT SLEEK DATE
 [D] PRIMA MINI II DATE
 [E] AUTOBOY F-XL

REF. NO. C13-3572
 C13-3573
 C13-3582
 C13-3583
 C13-3591



PARTS LIST

REF.No.C13-3572,73


C13-3582,83

C13-3591

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB1-3532-000	E	1	PANEL, FRONT
	CB1-3533-000	E	1	BAR, GUIDE
	CB1-3534-000	E	1	BAR, HELICAL
	CB1-3541-000	E	2	BEARING
	CB1-3546-000	D	1	SHEET1, FLOCKING
	CB1-3547-000	D	1	SHEET2, FLOCKING
	CB1-3548-000	D	1	SHEET3, FLOCKING
	CB1-3566-000	E	1	RING, ECCENTRIC
	CB1-3804-000	E	1	NUT
	CB1-3812-000	D	1	COVER, HIDING
	CB1-6021-000	C	1	PLATE, NAME RING
	CF1-3238-000	D	1	AF MOTOR ASS'Y
	CF1-3239-000	D	1	SWEDE RING ASS'Y
	CG1-1632-000	C	1	LENS BARREL ASS'Y
	CG9-0416-000	C	1	SHUTTER UNIT
	CH1-1318-000	C	1	FLEX, SHUTTER
	CS2-0991-000	E	1	GEAR1, AF
	CS2-0992-000	E	1	GEAR2, AF
	CS2-7218-000	D	1	SWITCH, AF
	XA4-4140-309		1	SCREW, CROSS-RECESS, PH
	XA4-9170-409		1	SCREW, CROSS-RECESS, PH
	XA4-9170-459		3	SCREW, CROSS-RECESS, PH
	XA4-9170-959		2	SCREW, CROSS-RECESS, PH

CANON [A] SURE SHOT SLEEK
 [B] PRIMA MINI II
 [C] SURE SHOT SLEEK DATE
 [D] PRIMA MINI II DATE
 [E] AUTOBOY F-XL

REF. NO. CI3-3572
 CI3-3573
 CI3-3582
 CI3-3583
 CI3-3591



PARTS LIST

REF.No.C13-3572,73


C13-3582,83

C13-3591

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB1-3499-000	E	1	HOLDER, CARTRIDGE
	CB1-3501-000	E	1	CONTACT, BATTERY(+)
	CB1-3503-000	E	1	SPROCKET
	CB1-3549-000	E	1	BASE, BLADE
	CB1-3578-000	E	1	P. N. INDICATION LEVER UNIT
	CB1-3579-000	E	1	PIN, PANORAMA
	CB1-3586-000	E	1	P. N. INDICATION FILM
	CF1-2899-000	E	1	ROLLER ASS'Y
	CG1-1634-000	D	1	FLASH BOARD 1 ASS'Y
	CG9-0424-000	D	1	FINDER UNIT
	CG9-0428-000	C	1	PANORAMA FINDER UNIT
	CG9-0432-000	D	1	PANORAMA LEVER UNIT
	CH1-1314-000	E	1	PLATE, SPROCKET
	CH6-2040-000	D	1	CAPACITOR, MAIN
	CS2-0989-000	E	1	GEAR, SPROCKET
	CS2-0990-000	E	1	IDLER, COUNTER
	CS2-6374-000	E	1	SPRING, BLADE
	CS2-6377-000	E	1	P. N. INDICATION SPRING
	CS2-7214-000	D	1	SWITCH1, SPROCKET
	CS2-7215-000	D	1	SWITCH2, SPROCKET
	XA4-6170-307		1	SCREW, CROSS-RECESS, PH
	XA4-6170-609		2	SCREW, CROSS-RECESS, PH
	XA4-9170-309		1	SCREW, CROSS-RECESS, PH
	XA4-9170-459		1	SCREW, CROSS-RECESS, PH
	YN2-0656-000	E	1	LENS, FIELD
	YN2-0657-000	E	1	PRISM
	YN2-0661-000	E	1	LENS, FIELD(P)

CANON [A] SURE SHOT SLEEK
 [B] PRIMA MINI II
 [C] SURE SHOT SLEEK DATE
 [D] PRIMA MINI II DATE
 [E] AUTOBOY F-XL

REF. NO. C13-3572
 C13-3573
 C13-3582
 C13-3583
 C13-3591




PARTS LIST

REF.No.C13-3572,73
C13-3582,83
C13-3591

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB1-1618-000	E	1	SPOOL
	CB1-3495-000	E	1	COVER, SPOOL
	CB1-3500-000	E	1	BODY
	CB1-3502-000	E	1	CONTACT, BATTERY(-)
	CB1-3525-000	E	1	COVER, BATTERY
	CB1-3529-000	E	1	SHAFT, BACK COVER
	CB1-3575-000	E	1	BLADE1, PANORAMA
	CB1-3576-000	E	1	BLADE2, PANORAMA
	CB1-4973-000		1	SCREW, CROSS-RECESS, PH
	CF1-2901-000	D	1	TRANS MOTOR ASS'Y
	CS2-0995-000	E	1	GEAR, TRANSFER
	XA4-9170-409		1	SCREW, CROSS-RECESS, PH
	XA4-9170-559		2	SCREW, CROSS-RECESS, PH


CANON [C] SURE SHOT SLEEK DATE
[D] PRIMA MINI II DATE
[E] AUTOBOY F-XL

REF. NO. C13-3582
C13-3583
C13-3591



CANON [A] SURE SHOT SLEEK
[B] PRIMA MINI II

REF. NO. C13-3572
C13-3573



PARTS LIST

REF.No.C13-3572,73
C13-3582,83
C13-3591

NEW	PARTS NO.	CLASS	QTY	DESCRIPTION
	CB1-3530-000	D	1	SHIELD, LIGHT
	CB1-6031-000	E	1	COVER, INNER QD
	CB1-6032-000	D	1	PLATE , PRESSURE
	CG9-0505-000	C	1	BACK COVER ASS'Y NON QD
	CH1-1428-000	E	1	FLEX, QD
	CH2-5195-000	D	1	SWITCH, DATE
	CH4-1021-000	C	1	MODULE, QD
	CS2-5665-000	D	1	SPRING, QD FLEX
	CS2-7216-000	E	1	SPRING, PRESSURE PLATE
	CY1-1830-000	D	1	COVER ASS'Y, BACK QD
	XA4-9170-259		4	SCREW, CROSS-RECESS, PH

ELECTRIC PARTS LIST

REF.No.C13-3572,73
C13-3582,83
C13-3591

NEW SYMBOL	PARTS NO.	CLASS	QTY	DESCRIPTION	REMARKS
IC4	WA3-6458-000	D	1	EEPROM	BR93LC46F
IC5	CH4-0597-000	E	1	M DRIVER	TA8312F
IC6	WA4-6334-000	E	1	IR DRIVER	MDG08
IC7	WA4-0904-000	E	1	REG	TA78L05F
LED 1	WG1-0506-000	E	1	LED, AF, AE	LTL-4231N
PC 1	WG8-5025-000	E	1	PHOTO INTERRUPTER	PS4704
PC 2	WG8-0148-000	E	1	PHOTO COUPLER, AF	ON217OR
OSC	WK2-5202-000	E	1	CERAMIC OSCILLATOR	CSAC4. 19MGCM
LAMP	WG1-5106-000	D	1	LAMP	OL-3453TPL
	CH2-3971-000			LEAD	BLUE
	Y11-2803-000			LEAD	RED
	Y11-2811-000			LEAD	BLUE
	Y11-3702-000			LEAD	BLACK
	Y11-3703-000			LEAD	RED
	Y11-3712-000			LEAD	PURPLE
	Y11-3713-000			LEAD	BROWN
	Y11-4402-000			LEAD	BLACK
	Y11-4403-000			LEAD	RED

